



acontis technologies GmbH

SOFTWARE

EC-Engineer

User Manual

Version 3.8

Edition: August 31, 2023

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

© Copyright **acontis technologies GmbH**

Neither this document nor excerpts therefrom may be reproduced, transmitted, or conveyed to third parties by any means whatever without the express permission of the publisher. At the time of publication, the functions described in this document and those implemented in the corresponding hardware and/or software were carefully verified; nonetheless, for technical reasons, it cannot be guaranteed that no discrepancies exist. This document will be regularly examined so that corrections can be made in subsequent editions. Note: Although a product may include undocumented features, such features are not considered to be part of the product, and their functionality is therefore not subject to any form of support or guarantee.

Contents

1	Introduction	6
1.1	Overview	6
1.2	Features	7
1.3	Supported Slaves of Beckhoff EL6xxx	9
1.4	Requirements	9
1.5	EtherCAT Slave descriptions (ESI files)	9
2	Installation	10
2.1	Setup Process	10
2.2	Silent Installation (optional)	13
2.3	File and Folder Structure	13
2.4	NDIS Driver	14
3	Getting Started	16
3.1	Offline Configuration	16
3.2	Online Configuration	18
3.3	Remote Configuration	19
3.4	Remote Diagnosis	20
3.5	Offline Configuration and Simulation	21
3.6	Offline Diagnosis	22
4	Graphical user interface	24
4.1	Overview	24
4.2	Menu/Tool/Status bar	25
4.2.1	File	25
4.2.2	View	25
4.2.3	Network	25
4.2.4	Settings	26
4.2.5	Help	26
4.3	Project Explorer	27
4.3.1	Configuration Mode	27
4.3.2	Diagnosis Mode	32
4.4	Device Editor	35
4.5	Short Info	35
4.6	Message Window	36
5	Configuration Mode	37
5.1	Overview	37
5.2	Master Settings	38
5.2.1	Master	38
5.2.2	Process Data Image	40
5.2.3	Watchlist	41
5.2.4	EtherCAT P Overview	41
5.2.5	Trace Data (Expert)	42
5.2.6	Advanced Options (Expert)	43
5.2.7	Slave to Slave (Expert)	45
5.2.8	Distributed Clocks (Expert)	46
5.2.9	Tasks + Sync Units (Expert)	48
5.2.10	Data Acquisition (Expert)	49
5.2.11	Motion Settings (Motion Mode only)	53
5.2.12	Scripts	53
5.2.13	Simulator Settings	54
5.3	Slave Settings	56
5.3.1	General	56

5.3.2	Modules	57
5.3.3	PDO Mapping	58
5.3.4	Variables	63
5.3.5	EtherCAT P	66
5.3.6	Advanced Slave Options (Expert)	67
5.3.7	(Hot Connect) Groups	70
5.3.8	Ethernet (EoE)	75
5.3.9	Distributed Clock (Expert)	76
5.3.10	Init Commands (Expert)	77
5.3.11	CoE Object-Dictionary (Expert)	80
5.3.12	SoE Object-Dictionary (Expert)	81
5.3.13	Sync Units (Expert)	82
5.3.14	Slave Specific Tabs (Expert)	82
5.3.15	IO-Link	88
5.3.16	Profibus Master (EL6731)	89
5.3.17	CANopen Master (EL6751)	89
5.3.18	CANopen Slave (EL6751-0010)	90
5.3.19	Motion (Motion Mode only)	91
5.3.20	Simulation Settings	92
5.4	Export ENI	96
5.5	Export EXI	96
6	Diagnosis Mode	97
6.1	Overview	97
6.2	Master	98
6.2.1	General (Master)	98
6.2.2	Process Data Image	99
6.2.3	Watch list	100
6.2.4	Performance	101
6.2.5	Trace Data (Expert)	103
6.2.6	CoE Object-Dictionary (Expert)	103
6.2.7	Master History (Expert)	105
6.3	Slave	106
6.3.1	General (Slave)	106
6.3.2	Variables	108
6.3.3	ESC Register (Expert)	109
6.3.4	EEPROM (Expert)	110
6.3.5	Extended Diagnosis (Expert)	112
6.3.6	DC Diagnosis (Expert)	113
6.3.7	CoE Object-Dictionary	114
6.3.8	SoE Object-Dictionary	117
6.3.9	File over Ethernet (FoE)	118
6.3.10	Slave History (Expert)	120
6.3.11	Motion (Motion Mode only)	121
6.3.12	Simulator (Simulator only)	122
7	Simulator Mode	124
8	Additional Tools	125
8.1	ESI-Manager	125
8.2	EMI-Manager	126
8.2.1	Administration	127
8.2.2	Supported Entries	128
8.3	Network Mismatch Analyzer	135
8.4	Line Crossed Analyzer	136
8.5	Inspection Report	137
8.6	EoE Endpoint Configuration	138
8.7	Edit Topology	140
8.8	Capture File	141


8.9	Project Templates	143
8.10	Real-time Support	145
8.10.1	Optimized Link Layers	145
8.11	Export ENI Variants	146
9	Command Line Interface	148
10	Customization	151
10.1	Multi-Language-Support	151
10.2	Themes	151
10.3	Integration into 3rd-Party Applications	156
11	Licensing	158
11.1	Third party Software	158
11.2	EC-Engineer License	158
11.3	Node Locked License	158
11.4	Floating License	158
11.4.1	Configure License Server	159
11.4.2	Configure Client Computer	160
11.5	License Update	162
11.5.1	Request License Update	162
11.5.2	Install License Update	166
11.6	Dongle Firmware Update	166
11.7	Expiration Date Dongle	168
12	FAQ, Tips	171
12.1	Problems with install or uninstall	171
12.2	Help in case of a problem	171
12.3	Shortcuts	171
12.4	Internal User Specific Settings	172
12.5	FAQ	173

1 Introduction

1.1 Overview


EC-Engineer is a configuration and diagnosis tool for EtherCAT networks that are controlled by the EC-Master.

The following screenshot shows the EC-Engineer in configuration mode:



It runs on the Engineering System where the engineer can configure the EtherCAT network. All slaves default to settings that match the Slave's typical use case. Complex networks or installations with special requirements need adjustments to the default settings. Using the Configuration Mode, the user can configure his EtherCAT network according to the project's needs.

As the result of his work the user can export the EtherCAT Network Information (ENI) file, which is necessary to run the EC-Master on the Control System:



If he has the possibility to connect his Engineering System to the Control System, he can also scan his existing EtherCAT network. The EC-Engineer will then read the network configuration and add all slaves to the project explorer. Now the user can fine tune the network or directly export the ENI file.

If the control system is now running, he can connect to it by using the remote diagnosis functionality and verify that everything is fine by accessing the states, variables, object dictionaries, ESC registers EEPROM data.

1.2 Features

The following table shows the features of the EC-Engineer:

General features	Feature ID	Free	Standard	Plus
Classic view	100	✓	✓	✓
Flat view	101	✓	✓	✓
Topology view	102	✓	✓	✓
Multiple Instances	103	✓	✓	✓
Different themes	104	✓	✓	✓
Different Languages	105	✓	✓	✓
Command line interface	106	✓	✓	✓
EMI Manager	107	✓	✓	✓
ESI Manager	108	✓	✓	✓
Expert Mode	109	✓	✓	✓
Edit topology view	110	✓	✓	✓
Offline Diagnosis	111	✗	✓	✓
Unlimited Slave Count	112	✗	✓	✓

Configuration features	Feature ID	Free	Standard	Plus
Set up distributed clocks	200	✓	✓	✓
Configure MDP slaves	201	✓	✓	✓
Custom PDO mapping	202	✓	✓	✓
Changing name of variables	203	✓	✓	✓
Group support / Hot Connect / Pinned Group	204	✓	✓	✓
EoE Support	205	✓	✓	✓
Startup Commands	206	✓	✓	✓
CoE Object-Dictionary (offline)	207	✓	✓	✓
Enable / disable slave	208	✓	✓	✓
Slave to Slave	209	✓	✓	✓
Support gateway slaves (EL6692, EL6224, EL6631-0010, ...)	210	✓	✓	✓
Export ENI-File	211	✗	✓	✓
Export Process variables	212	✓	✓	✓
Multiple Cyclic Tasks	213	✗	✓	✓
Import slaves from ENI	214	✓	✓	✓
SoE Object-Dictionary (offline)	215	✓	✓	✓
Change revision of slave	216	✓	✓	✓
Scan topology of local system	217	✓	✓	✓
Scan topology of remote system	218	✗	✓	✓
Scan PDO configuration from slave	219	✓	✓	✓
Scan MDP configuration from slave	220	✓	✓	✓
Define project templates	221	✗	✓	✓
Support gateway masters (EL6751, EL6731, ...)	222	✗	✓	✓
EtherCAT P support	223	✓	✓	✓
Slave to Slave in Cycle	224	✗	✓	✓

Diagnosis features	Feature ID	Free	Standard	Plus
Watch list with export	300	✓	✓	✓
ESC Register	301	✓	✓	✓
FoE support	302	✗	✓	✓
DC Diagnosis	303	✓	✓	✓
Extended Diagnosis	304	✓	✓	✓
Trace Data Variables	305	✓	✓	✓
EoE endpoint support	306	✗	✓	✓
Export CoE Object-Dictionary	307	✓	✓	✓
Local System with Windows Master	308	✓	✓	✓
Remote System via RAS-Client	309	✗	✓	✓
Reading count of slaves or frames	310	✓	✓	✓
Compare configured and found slaves	311	✓	✓	✓
See value of variables in a list view or chart view	312	✓	✓	✓
Changing value of a variable	313	✓	✓	✓
Reading/Writing values (CoE OD)	314	✓	✓	✓
EEPROM Reading/Writing values	315	✗	✓	✓
Reading error or frame counters	316	✓	✓	✓
Diagnosis History of master or slave	317	✓	✓	✓
Reading/Writing values (SoE OD)	318	✓	✓	✓

1.3 Supported Slaves of Beckhoff EL6xxx

The following table shows the supported slaves of Beckhoff EL6xxx in the EC-Engineer:

Name	Free	Standard	Plus
EL6001 Interface (RS232)	✓	✓	✓
EL6002 Interface 2Ch. (RS232)	✓	✓	✓
EL6021 Interface (RS422/485)	✓	✓	✓
EL6021-0021 Interface (RS422/485 line device)	✓	✓	✓
EL6022 Interface 2Ch. (RS422/485)	✓	✓	✓
EL6080 EtherCAT Memory Terminal (128kB)	✓	✓	✓
EL6224 / EP6224 IO-Link Gateway	✓	✓	✓
EP6228 / EPP6228 IO-Link Gateway	✓	✓	✓
EL6601 1 Port Switch (Ethernet, CoE)	✓	✓	✓
EL6614 4 Port Switch (Ethernet, CoE)	✓	✓	✓
EL6631-0010 PROFINET IO Device	✓	✓	✓
EL6690 EtherCAT Bridge terminal (Primary)	✓	✓	✓
EL6690 EtherCAT Bridge terminal (Secondary)	✓	✓	✓
EL6692 EtherCAT Bridge terminal (Primary)	✓	✓	✓
EL6692 EtherCAT Bridge terminal (Secondary)	✓	✓	✓
EL6695 EtherCAT Bridge terminal (Primary)	✓	✓	✓
EL6695 EtherCAT Bridge terminal (Secondary)	✓	✓	✓
EL6731 PROFIBUS DP Master	✗	✗	✓
EL6731-0010 PROFIBUS DP Slave	✓	✓	✓
EL6751 CANopen Master	✗	✗	✓
EL6751-0010 CANopen Slave	✗	✗	✓

Not listed devices are not supported.

1.4 Requirements

- Microsoft Windows 10 and above
- Microsoft .NET Framework 4 Client Profile
- Screen resolution at least 1024x768 pixel
- Memory as recommended for operating system
- Disk space approximately 80 MB (depend on number of ESI files)

1.5 EtherCAT Slave descriptions (ESI files)


The EC-Engineer needs information about each Slave Type to correctly initialize it, give reasonable default settings and present the configurable properties to the user. The knowledge about the different Slave types is gathered from ESI files. The ESI files can be managed by the *ESI-Manager*.

2 Installation


2.1 Setup Process

The product can be installed by executing the `setup.exe` (requires administrator privileges) and follow the screen instructions:


Welcome page:




License Agreement:




Select Installation Folder:




Confirm Installation:



Installing EC-Engineer:



Installation Complete:



2.2 Silent Installation (optional)

The product can be also installed in silent mode by using the command line parameters of `msiexec`.

Sample 1: Installs EC-Engineer into default installation folder

```
$ msiexec /i c:/temp/ECEngineerSetup.msi /quiet /qn /norestart /log  
→ c:/temp/install.log
```

Sample 2: Installs EC-Engineer into C:/EC-Engineer

```
$ msiexec /i c:/temp/ECEngineerSetup.msi /quiet /qn /norestart /log  
→ c:/temp/install.log INSTALLLOCATION="C:/EC-Engineer"
```

For more information please refer command line parameters of `msiexec`.

Note: The system requirements *Supported Slaves of Beckhoff EL6xxx* will be not checked!

2.3 File and Folder Structure

The setup process will copy all necessary files into the following folder:

Installation directory: (Default: `%ProgramFiles%/acontis_technologies/EC-Engineer`)

- /Doc**
Release notes and the user manual
- /EEC**
Files for mapping emergency error codes
- /Languages**

- Language specific files
- EC-Engineer.exe
- EcMaster.dll
- ...

All users directory: (%ALLUSERSPROFILE%/EC-Engineer, like C:/ProgramData/EC-Engineer)

/CAPTURE

Capture files which can be analysed in offline diagnosis mode (see *Capture File*)

/EtherCAT

EtherCAT Slave Information (ESI) Files Can be modified via *ESI-Manager*

/EMI

EtherCAT Master Information files (see *Themes*)

ESICache.xml

ESI-File-Cache for faster access of ESI files

EC-Engineer.log

Log file



User.myusername.xml

User specific settings

2.4 NDIS Driver

The Network Driver Interface Specification (NDIS) is the specification for a network driver architecture that allows transport protocols like TCP/IP to communicate with an underlying physical network adapter. For sending and receiving EtherCAT frames in Windows, EC-Engineer makes use of the well-known Windows packet capture library, WinPcap. However, WinPcap was based on the NDIS 5.x driver model, and development has ceased. The latest versions of Windows 10 do not support this old NDIS 5.x version anymore, so now EC-Engineer (V3.2 and higher) includes an installation package in the install directory of EC-Engineer to install the acontis NDIS 6.x Filter Module `EcatNdis.sys`. With this new Filter Module and the new NDIS Link Layer `emllNdis.dll`, it is now possible for EC-Engineer to work without WinPcap on all Windows 10 versions.


Note: Please restart EC-Engineer after the NDIS installation.



3 Getting Started

For a better usability, the product comes up with a start page, where the user can choose what he wants to do:


Getting Started




3.1 Offline Configuration

This mode is for configuring the EtherCAT network in the office by manually adding slaves to the network.

If the user clicks on this link he will see first the *Select Master Unit Dialog* for choosing the desired master unit (at the moment he can choose between Class A and Class B master):



Afterwards he will see the *Slave Select Dialog*, where he can configure his EtherCAT network:




If you can not find your slave or if you want to use your own *ESI* file, you can edit this list by using the *ESI-Manager*. After configuring the network you can select the *network* node and use the *Export ENI* button for generating an *ENI* file.


3.2 Online Configuration

This mode can be used if slaves are connected to the Engineering System by scanning the EtherCAT network configuration.

If user clicks on this link he will see first the *Select Master Unit Dialog* for choosing the desired master unit (at the moment he can choose between Class A and Class B master):



Afterwards he will see the *Master-Tab*, where he can choose the network adapter which is connected to the control system:




After selecting the network adapter, the EC-Engineer scans the control system and adds the network configuration to the project explorer. Here the user can adjust the configuration or use the *Export ENI* button for generating directly an ENI file.

Note: Please make sure that the selected network adapter is connected to the EtherCAT slaves.


3.3 Remote Configuration

This mode can be used if slaves are connected to the control system. Means user can connect via TCP/IP to the control system if EC-Master RAS (remote access service) server is running and scan the EtherCAT network configuration.

If user clicks on this link he will see first the *Select Master Unit Dialog* for choosing the desired master unit (at the moment he can choose between Class A and Class B master):



Afterwards he will see the *Master-Tab*, where he can enter the IP address of the remote system (and if necessary change the port and the master-instance, but normally this should not be necessary):




After entering the IP address, a click to *Select* tells the EC-Engineer to connect to and scan the remote system. The EC-Engineer adds all Slaves of the network configuration to the project explorer. Here the user can adjust the configuration or use the *Export ENI* button for generating directly an ENI file.


3.4 Remote Diagnosis

This mode should be used if the EC-Master is already running on the control system and the user wants to take a look into the “health” of the EtherCAT system.

If user clicks on this link he will see first the *Select Master Unit Dialog* for choosing the desired master unit (at the moment he can choose between Class A and Class B master):



Afterwards he will see the *Master-Tab*, where he can enter the IP address of the remote system (and if necessary change the port and the master-instance, but normally this should not be necessary):




After entering the IP address, a click to *Select* switches the EC-Engineer into Diagnosis Mode. There the user sees the “health” of his EtherCAT system.


3.5 Offline Configuration and Simulation

This mode is for configuring the EtherCAT network in the office by manually adding slaves to the network.


If the user clicks on this link he will see first the *Select Master Unit Dialog* for choosing the desired master unit (at the moment he can choose between Class A and Class B master):



Then the user have to select the simulator:



Afterwards he will see the *Slave Select Dialog*, where he can configure his EtherCAT network:




If you can not find your slave or if you want to use your own `ESI` file, you can edit this list by using the *ESI-Manager*. After configuring the network you can select the *network* node and use the *Export ENI* button for generating an ENI file or switch to diagnosis mode and simulate the network.


3.6 Offline Diagnosis

This mode should be used if the user wants to analyse a previously created capture file. This can be done offline, which means that the “real system” no not necessary.

If user clicks on this link he will see first the *Select Master Unit Dialog* for choosing the desired master unit (at the moment he can choose between Class A and Class B master):



Afterwards he will see the *Master-Tab*, where he can enter the path to the capture, which contains one or more previously taken snapshots:



The screenshot shows the 'Device Editor' window with the 'Master' tab selected. The interface includes several sections for configuration:

- General**: Unit Name (Class-A Master), Cycle Time [us] (1000), Source MAC address (A0-36-9F-30-00-3B).
- Slaves connected to local system**: Link Layer (Ndis), Network Adapter (EtherCAT-Test (Intel(R) Ethernet Server Adapter I210-T1)). A 'Deselect' button is present.
- Slaves connected to remote system**: Protocol (RAS), IP Address (127 . 0 . 0 . 1), Port (6000), Master-Instance (0). A 'Select' button is present.
- Slaves simulated (SiL)**: A 'Select' button is present.
- Slaves captured**: Capture File (empty text box). A 'Select' button is present.


The 'Slaves captured' section is highlighted with a red border in the original image.

After choosing the path to the capture file, a click to *Select* switches the EC-Engineer into Diagnosis Mode. Now, the user can analyse the previously taken snapshots of a EtherCAT system.

4 Graphical user interface

4.1 Overview

This section gives an overview about the graphical user interface:



The graphical user interface is divided into five parts:

Menu/Tool/Status bar:

Shows current status or mode of the EC-Engineer and allows the user to change it.

Project Explorer:

Shows different views of the current network configuration and allows the user to change it by adding or removing devices/slaves/modules.

Device Editor:

Show information about the selected device, like process variables or PDO mappings. It allows the user also change this information.

Short Info:

Show short information about selected device, like name, description or vendor.

Messages:

Shows notifications which occur e.g. when the EtherCAT Master has changed its operation state or a slave has been removed from (or added to) the EtherCAT network.

4.2 Menu/Tool/Status bar

4.2.1 File

New / Open / Save / Save As / Print:

Start new configuration or open/save/print existing configuration

Add Master-Unit:

Add a new Master-Unit to the configuration. At the moment we have three Master-Units:

- EtherCAT Master Unit (Class A)
- EtherCAT Master Unit (Class B)

ESI-Manager:

Add, delete or export ESI and SCI files (see: *ESI-Manager*)

EMI-Manager:

Add, delete or modify EMI files (see: *EMI-Manager*)

Recent Projects:

Open recent project

Exit:

Closes the EC-Engineer

4.2.2 View

Message Window:

Shows/Hides the message window

Short-Info Window:

Shows/Hides the short-info window

Expert Mode:

(De-)Activates expert mode

Motion Mode:

(De-)Activates motion mode

Refresh:

Updates the current view

4.2.3 Network

Scan EtherCAT Network:

Scans the connected network for slaves

Edit Topology:

Opens a dialog to change the current topology of the project and a bus merge is possible (for more information see *EoE Endpoint Configuration*)

Export ENI File / Export ENI Variants / Import ENI File / Process Variables / EEPROM File

Creates an ENI file, or ENI variants (see *Export ENI Variants*) / imports an ENI file or export the process variables or the eeprom to a file

Network Mismatch Analyzer (active only in diagnosis mode):

Compares the configured slaves with the connected slaves. See *Network Mismatch Analyzer*

Line Crossed Analyzer (active only after scan):

Shows wrong connected slaves. See *Line Crossed Analyzer*

Inspection Report (active only in diagnosis mode):

Opens a statistic about the state of the network. Collects some useful data like error counters and so on. Possibility to print a PDF. See *Inspection Report*

Clear Error Counters (active only in diagnosis mode):

Clears the error counters of all connected slaves (for more information about the extended diagnosis, see *Extended Diagnosis (Expert)*)

Acknowledge all warnings (active only in diagnosis mode):

Clears the yellow warning icon of all slaves

Self Test Scan:

Executes a self test routine for EC-Master and the network

Rescue Scan:

Executes the rescue scan. Can help if frames get lost with a switch for example

Take Snapshot (active only for local or remote system):

Takes a snapshot from the current diagnosis state and saves it into a capture file (for more information about the snapshots and capture files, see *Capture File*)

Automatic Snapshot Mode (active only for local or remote system):

Activates the automatic snapshot mode to take snapshots based on the configured rules

Snapshot (active only for offline diagnosis system):

Changes the active snapshot

EoE Endpoint Configuration (active only for local or remote system):

Activates EoE Endpoint support in diagnosis mode

4.2.4 Settings

Language:

Changes the current language

Theme:

Changes the current theme

Message Level:

Change the current message level

Capture File:

Shows capture file settings dialog

Project Template:

Shows project template settings dialog

4.2.5 Help

Show User Manual:

Shows this user manual

Show Log File:

Shows the log file

Check for updates:

Enable / disable automatic update check (once per month). Also a manual update check is performed on activation.

About ...:


Show the about dialog

4.3 Project Explorer

4.3.1 Configuration Mode


There are three topology visualisation views:

Classic View




This is a tree view which has two levels. In the first level you can find coupler slaves or MDP slaves and in the second level you will see the connected slaves/modules.

Flat View



This view shows all slaves in a flat list, as they are connected in the EtherCAT network.

Topology View



This view shows a graphical tree of all slaves, as they are connected in the EtherCAT network.

The context menu of one or more selected slaves has the following entries:

Append Slaves:

Appends a new slaves

Remove Slaves:

Deletes the selected slaves

Cut/Copy/Paste:

Extended clipboard operations, which should help the user to move or multiply existing slave definitions.

Enable Slaves:

Appends disabled slaves to the process image at the previous position. If this is not possible, the slave will be marked as “not connected” and the user can append the slave by using “cut” & “paste”.

Disable Slaves:

Removes the slaves from process image and from the exported ENI file, but keeps the slave as “disabled”

in the project.

Reload ESI data:


Reloads ESI data which are stored in the project file from global ESI cache (after adding a slave to the project the ESI data will be stored in the project file).

Export SCI:

Exports a SCI file. A SCI file is like an ESI file but preconfigured. So it is possible to create a fixed slave which can be added to the configuration and is working out of the box.

Change Slave:

Opens the following dialog, where the user can select a compatible slave (this is helpful, if the user wants to update the slave to a new revision and keeps his configuration). This is also used to change from an ESI to a SCI file.



Import Beckhoff Slave Description, to import slave settings from TwinCAT (or ET9000)


Import slave settings from “Beckhoff Slave Description” files

- Open project in TwinCAT
- Select slave to export
- Main menu “TwinCAT”
- Selected Item
- Export XML Description
- Import the exported file (imported will be MDP configuration, PDOs, DC settings, ...)

Import init commands of slave from “Beckhoff Init Command Description” files

- Open project in TwinCAT
- Select slave to export
- Open tab “Startup”
- Context menu: “Export to XML”
- Import the exported file (imported will be the exported init commands)

If user tries to append slave he will see the following dialog:



Filter

Search: Keyword to filter the slaves by type name. Vendors: List of all available vendors. User can filter all slaves by selecting the desired vendor from the list. If it makes sense, the recommended vendor is already preselected, e.g. if you try to append a slave to an E-Bus. Show Hidden Slaves: Shows also hidden slaves (e.g. with older revisions, if newer slaves are available) Show Preconfigured Slaves: Shows also slaves from SCI files

Connection

Select the port where the predecessor device is connected (see *General*).

List of available slaves


User can select the slave which he wants, by expanding the three levels: vendors, groups and the slaves themselves. The 3rd level consists of three parts: Type name, description and the revision number.

Number of slaves

User can change this value if he wants to add more than one slave of the same type.

4.3.2 Diagnosis Mode

There are three topology visualisation views:


Classic View

This is a tree view which has two levels. In the first level you can find coupler slaves and in the second level you will see the connected slaves.

Possible device states:

-  Init Bootstrap
-  Pre-Op
-  Safe-Op
-  Op

Flat View




This view shows all slaves in a flat list, as they are connected in the EtherCAT network.

Possible device states:

-  Init Bootstrap
-  Pre-Op
-  Safe-Op
-  Op

Topology View






This view shows a graphical tree of all slaves, as they are connected in the EtherCAT network.

Possible device states:

-  Init Bootstrap
-  Pre-Op
-  Safe-Op
-  Op


Possible port states:

-  Bad Cable Quality
-  Constricted Cable Quality
-  Good Cable Quality

If cable quality is constricted or bad, please check the error counters of the slave (for more information about the extended diagnosis, see *Extended Diagnosis (Expert)*).

4.4 Device Editor


This Editor gives the user the possibility to read and write information of the selected master or slave:



Some tabs in the Device Editor are Expert Settings. The menu item *View Expert Settings* enables or disables the Expert Settings' visibility. Some tabs appear when configuring the first Slave.


4.5 Short Info

This window shows short information about selected device, like name, description or vendor:



4.6 Message Window

Shows notifications which occur e.g. when the EtherCAT Master has changed its operation state or a slave has been removed from (or added to) the EtherCAT network:




Severity	Time	Message
INF	14:21:16	Master state change from 'Init' to 'Pre-Op'
INF	14:21:13	Master state change from 'Unknown' to 'Init'
INF	14:21:12	Master state change from 'Unknown' to 'Init'
INF	14:21:09	Network scan successful - 26 slaves found

5 Configuration Mode

5.1 Overview

The EC-Master needs the EtherCAT-Network-Information (ENI) file to initialize and control the EtherCAT network. In most cases the automatically generated Slave settings can be used to run the EtherCAT network. In this chapter you can read how EC-Engineer helps you to view or adjust those settings.

At startup of EC-Engineer, the user will see this page:



It consists of three sections:

- Add Master Unit: List of available master units
- Recent Projects: List of the last five opened projects
- Getting Started: List of available run modes


If the user clicks on one of the links, it runs a new master unit, opens an already existing project or switches in the “Getting Started” mode.

5.2 Master Settings

This section includes network related or master related settings. Some of those settings will also affect the “Master” section of the ENI.

5.2.1 Master

In this tab, the user can configure the name of the master and the cycle time. If he wants to connect to a control system, this can be also configured:



General

Unit Name:

Name of the master device

Cycle Time:

Interval in microseconds in which all EtherCAT commands will be sent from the master. The user can choose between the following values: 125, 250, 500, 1000, 2000 and 4000.


Source MAC address:

MAC address of the connected system (will be filled during bus scan)

Slaves connected to local system

Network Adapter:

Network adapter which is connected to the control system. In newer versions it is also a possibility to select the Link-Layer.



Slaves connected to remote system

Protocol:

Protocol of the remote system

- RAS (Default port is 6000)
- **Mailbox Gateway (Default port is 34980)**
 - EC-Master V3.0.1.22 and above
 - TwinCAT 3.1.4024 or TwinCAT 3.1.4022.30 and above

IP Address:

IP address of the remote system, which is connected to the control system

Port:

Port of the remote system, which is connected to the control system

Master-Instance:

Used to determine which master instance should be used in the remote system (Master supports up to 10 instances).


Data to load from capture file

Capture File:

Path to the capture file, which contains one ore more snapshots

5.2.2 Process Data Image

In this tab, the user can see all variables of the process data image. If he wants, he can also export the list:



Device Editor

Master | Process Data Image | Watch list | EtherCAT P | Trace Data | Advanced Options | Slave to Slave | Distributed Clocks | Tasks + Sync Units | Data Acquisition

Variables Export


Name	Datatype	Master Sync Unit	Offset	Size
Slave_1002 [IndraDrive MPC17 (1 CCD Master +0 CCD Slaves)],AT (CCD Master),Drive status word	UINT	Id 0: Default 0	IN : 0.0	2.0
Slave_1002 [IndraDrive MPC17 (1 CCD Master +0 CCD Slaves)],AT (CCD Master),Position feedback value 1	DINT	Id 0: Default 0	IN : 2.0	4.0
Slave_1003 [EPP2308-0001],Channel 1.Input	BOOL	Id 0: Default 0	IN : 6.0	0.1
Slave_1003 [EPP2308-0001],Channel 2.Input	BOOL	Id 0: Default 0	IN : 6.1	0.1
Slave_1003 [EPP2308-0001],Channel 3.Input	BOOL	Id 0: Default 0	IN : 6.2	0.1
Slave_1003 [EPP2308-0001],Channel 4.Input	BOOL	Id 0: Default 0	IN : 6.3	0.1
Slave_1005 [EPP1004-0061],Channel 1.Input	BOOL	Id 0: Default 0	IN : 7.0	0.1
Slave_1005 [EPP1004-0061],Channel 2.Input	BOOL	Id 0: Default 0	IN : 7.1	0.1
Slave_1005 [EPP1004-0061],Channel 3.Input	BOOL	Id 0: Default 0	IN : 7.2	0.1
Slave_1005 [EPP1004-0061],Channel 4.Input	BOOL	Id 0: Default 0	IN : 7.3	0.1
Slave_1006 [EPP1004-0061],Channel 1.Input	BOOL	Id 0: Default 0	IN : 7.4	0.1
Slave_1006 [EPP1004-0061],Channel 2.Input	BOOL	Id 0: Default 0	IN : 7.5	0.1
Slave_1006 [EPP1004-0061],Channel 3.Input	BOOL	Id 0: Default 0	IN : 7.6	0.1
Slave_1006 [EPP1004-0061],Channel 4.Input	BOOL	Id 0: Default 0	IN : 7.7	0.1
Slave_1007 [EPP1004-0061],Channel 1.Input	BOOL	Id 0: Default 0	IN : 8.0	0.1

Add to watch list

Edit Variable

Move Up Move Down New Edit Delete

If user wants to export the variables, he will see the following dialog:




Export Formats:

- CSV File (Semicolon separated text file)
- CSV PLC File (Semicolon separated text file, where offsets are in PLC format)
- PD Layout File (C-Header file which can be used from EC-Master-Demo application)
- XML File (Like ProcessImage in ENI)

5.2.3 Watchlist

In this tab, the user can see all variables which were added to the watchlist in config mode:



The screenshot shows the 'Device Editor' interface with the 'Watch list' tab selected. The 'Variables' section contains a table with the following data:

Name	Datatype	Master Sync Unit	Offset	Size
Slave_1007 [EL1018].Channel 6.Input	BOOL	Id 0: Default 0	IN : 154.5	0.1
Slave_1003 [EL2008].Channel 3.Output	BOOL	Id 0: Default 0	OUT : 154.2	0.1
Slave_1013 [EL4132].Channel 2.Output	INT	Id 0: Default 0	OUT : 170.0	2.0

Below the table, there is an 'Export' button and a 'Remove from watch list' button. At the bottom, there is an 'Edit Variable' section with 'Move Up', 'Move Down', 'New', 'Edit', and 'Delete' buttons.

The variables can be edited and removed from the watchlist.

5.2.4 EtherCAT P Overview

In this tab, the user can check the EtherCAT P system, if there are EtherCAT P slaves in the configuration. For those EtherCAT P slaves, he can calculate and check the power consumptions in the EtherCAT P segments based on cables and loads:

Device Editor

Master | Process Data Image | Watch list | **EtherCAT P** | Trace Data | Advanced Options | Slave to Slave | Distributed Clocks | Tasks + Sync Units | Data Acquisition

EtherCAT P Checking

Slave_1004 [EPP1322-0001] (Power Sourcing Devices) Validate

Name	Us(V)	Up(V)	Is(A)	Ip(A)	Us Load	Up Load	Us Load Type	Up Load Type
Slave_1004 [EPP1322-0001]	24,00	24,00	0,342	0	---	---	---	---
Slave_1003 [EPP2308-0001]	23,92	24,00	0,242	0	0 W	0 W	Sw Regulator	Sw Regulator
Slave_1005 [EPP1004-0061]	23,86	24,00	0,181	0	0 W	---	Sw Regulator	---
Slave_1006 [EPP1004-0061]	23,82	24,00	0,121	0	0 W	---	Sw Regulator	---
Slave_1007 [EPP1004-0061]	23,80	24,00	0,061	0	0 W	---	Sw Regulator	---

In the ComboBox the user can switch between all Power Sourcing Devices (PSD) in the configuration. In the grid are shown all the supplied slaves from the selected PSD, with the calculated voltages and currents and the selected loads. The values which are to high or to low are marked red.

Hint: These values are not relevant for the ENI-File. They are just a help for the user what might not work. The ENI File can be exported anyway.

On the *Validate* Button, the user can check the whole configuration. If there is an error somewhere, the corresponding PSD is selecte. If there are no errors the user will get a message box.

5.2.5 Trace Data (Expert)

In this tab, the user can add trace variables:

Device Editor

Master | Process Data Image | Watch list | Trace Data | **Advanced Options** | Slave to Slave | Distributed Clocks | Tasks + Sync Units | Data Acquisition

Master Settings

Init Command Retries:

Slave Settings

Startup Checking

- Check Vendor ID
- Check Product Code
- Check Revision Number
 -
- Check Serial Number

Identification Checking

- Check Identification
 - Use Current Values
 - Copy Station Address -> Identification Value
 - Copy Identification Value -> Station Address

Process Data Mode

- Disable LRW

Overwrite Watchdog

- Set Multiplier (Reg.: 0x400):
- Set PDI Watchdog (Reg.: 0x410):
- Set SM Watchdog (Reg.: 0x420):

Timeouts

- SDO Access: [ms]
- Init->Pre-Op/Init->Bootstrap: [ms]
- Pre-Op->Safe-Op/Safe-Op->Op: [ms]
- Back to Pre-Op, Init: [ms]
- Op->Safe-Op: [ms]

Mailbox Mode

- Cyclic [ms]
- State Change

Overwrite Mailbox Size

- Output Size: [bytes]
- Input Size: [bytes]

Process Data Sync Manager Mode

- Default
- Buffered (3 buffer mode)
- Mailbox (Single buffer mode)

Apply changes to all slaves...

Master Settings

Init Command Retries: Number of retries, to handle transmission errors.

Slave Settings

- Slave settings can be applied to all slaves with one click on the button *Apply changes to all slaves*. For a detailed description of the Advanced Slave Options, see *Advanced Slave Options (Expert)*.
- **Identification Checking**
Use Current Values Identification Checking will be activated for all slaves with the current values

Important: If current is 0, the Identification is not activated!

Copy Station Address -> Identification Checking will be activated for all slaves with the station address as identification value

Copy Identification Value -> Identification Checking will be activated for all slaves and the identification value is also used as station address


5.2.7 Slave to Slave (Expert)

In this tab, the user can configure the slave to slave communication by connecting 2 variables or PDOs.

This tab consists of 2 views:


Default view

In this view, the user can configure the slave to slave communication by using copy infos in ENI file. This is the default way.



In cycle view

In this view, the user can configure the on cycle slave to slave communication by setup the process image and the FMMU in a way that inputs of the source slave will be directly written into the outputs of the destination slave during one cycle.




Limitations of one cycle slave to slave communication:

- Input slave must be located before output slave
- Complete sync unit of the slave must be connected (this means all PDOs of a sync unit must be connected and not only one variable)

5.2.8 Distributed Clocks (Expert)

In this tab, the user can change distributed clock related settings:



Reference Clock

Name:

Name of the reference clock. By default, this is the first slave with DC support.

Clock Adjustment

Master Shift:

The reference clock controls the Master time

Bus Shift:

The Master time controls the reference clock

External Mode:

The reference clock is controlled by an external sync device

Options

Sync Window Monitoring:

A command (datagram) will be inserted in the cyclic frame to read the ESC registers 0x092C. If this is selected the master will throw a notification.

Show 64Bit System Time:


Master supports slaves with 32bit and 64bit system time register (0x0910). If this is selected he will interpret it as 64bit system time.

Slaves with active DC

Shows a list of all slaves with active DC.

5.2.9 Tasks + Sync Units (Expert)

In this tab, the user can define additional cyclic tasks and master sync units. After adding a new master sync unit, the user can assign one or more slave sync units on tab *Slave Sync* ▶ *Units* to this master sync unit:




Tasks:

List of cyclic tasks and master sync units.

Buttons:

New/Edit/Delete: Used for changing the list.

If user wants to edit a task, he will see the following dialog:




Comment:

Comment of this task (will be written to ENI file)

Cycle Time:

Cycle time of this task

If user wants to edit a master sync unit, he will see the following dialog:



Name:

Name of this master sync unit (will be written to ENI file)

Sync Unit Id:

Id of this master sync unit (will be written to ENI file).

- ID 0 .. 9: Generated / internal master sync unit
- ID 10 .. 999: Generated / internal master sync unit for groups
- ID 1000 .. 2000: User defined master sync unit

Task Id:

Task Id to which is this master sync unit assigned

Offsets:

Activate to pin this master sync unit to a specific offset

Input:

Input offset of pinned master sync unit

Output:

Output offset of pinned master sync unit

5.2.10 Data Acquisition (Expert)

In this tab, the user can configure our Data Acquisition (DAQ) library. This library can be used from EC-Master to record process data in realtime.

After adding a new recorder, the user can select the variables which should be recorded and specify some triggers:

Device Editor

Master | Process Data Image | Watch list | Trace Data | Advanced Options | Slave to Slave | Distributed Clocks | Tasks + Sync Units | Data Acquisition

Variables Export Recorder 1

Name	Datatype	Offset	Size	Recorded
Slave_1025 [EL7031].STM Control.Control_Reset	BOOL	OUT : 143.1	0.1	<input type="checkbox"/>
Slave_1025 [EL7031].STM Control.Control_Reduce torque	BOOL	OUT : 143.2	0.1	<input type="checkbox"/>
Slave_1025 [EL7031].STM Velocity.Velocity	INT	OUT : 145.0	2.0	<input type="checkbox"/>
Slave_1026 [EL7201].DRV Controlword.Controlword	UINT	OUT : 147.0	2.0	<input type="checkbox"/>
Slave_1026 [EL7201].DRV Target velocity.Target velocity	DINT	OUT : 149.0	4.0	<input type="checkbox"/>
Slave_1002 [EL2008].Channel 1.Output	BOOL	OUT : 153.0	0.1	<input checked="" type="checkbox"/>
Slave_1002 [EL2008].Channel 2.Output	BOOL	OUT : 153.1	0.1	<input type="checkbox"/>

No longer record

Triggers

Left Operand	Operator	Right Operand	Enable	Start	Duration	Count
Slave_1014 [EL3162].Channel 1.Value	=	3	True	True	10	0
Slave_1002 [EL2008].Channel 1.Output	=	1	True	True	0	0
Slave_1002 [EL2008].Channel 1.Output	=	Slave_1002 [EL2008].Channel 3.Output	True	True	0	0

Edit Trigger New Edit Delete

Variables:

Add/Remove:


Used for adding or removing the selected variable to the recording.

Triggers:

New/Edit/Delete:

Used for changing the trigger list.

If user wants to edit a recorder, he will see the following dialog:



Edit Recorder

General

Name: Recorder 1

File: Recorder.mf4

Format: MDF

Frequency

Sample rate: 1

Cycle time: 1000 [µs]

Sample time: 1000 [µs]

Optional

Real time stamp:

Cycle counter:

Auto start:

OK Cancel

Name:

Name of the recorder

File:

Absolute path of the recorder file on the master system

Format:**Format of the recorder file, e.g.**

- MDF (Measurement Data Format)
- CSV (Comma Separated Values)

Sample Rate:

Sample rate of the recorded data e.g. every cycle or every second cycle, ...


Real time stamp:

Adds a real time stamp to the recorded data

Cycle counter:

Adds a cycle counter to the recorded data

If user wants to edit a trigger, he will see the following dialog:



General

Left variable:

Name of the left variable

Operator:

Operator of the trigger (e.g. =, >, >=, <, <=, !=)

Right value:

Value of the right operand to compare the left variable against a static value e.g. trigger, if variable is greater than 5

Right variable:

Name of the right variable to compare the left variable against the value of another variable e.g. trigger, if variable 1 is smaller than variable 2

Enable:

Enabled or disabled trigger (can be enabled from application later)

Start:

Start or stop trigger

Optional

Duration:

Duration in ms (0 = infinite) e.g. trigger should start recording for 500 ms

Count:

Trigger count (0 = infinite) e.g. trigger should hit only for 5 times

For more information please refer the manual of the EC-Master-Data-Acquisition-Library.

5.2.11 Motion Settings (Motion Mode only)

In this tab, the user change settings for the EcMasterDemoMotion Configuration. It is also possible to export the DemoMotionConfig.xml file:





Fig. 1: When “Use local EcMasterDemoMotion” is selected, the ENI and the config files are automatically exported to the EC-Engineer Motion folder in ProgramData when switching to diagnosis mode. With the Motion EMI, the script automation is activated. Per default when switching to diagnosis mode the EcMasterDemoMotion.exe is started and EC-Engineer connects with RAS. So it is very simple to start with Motion directly in EC-Engineer.

5.2.12 Scripts

In this tab, the user can select scripts that are executed in the different modes. The tab is only visible when the script mode is activated in the EMI file:




The first procedure is for scanning the network. There is the possibility of starting two scripts before the scan, and two scripts after the scan. It is also possible to set a delay between them. A usecase for this could be to start e.g. LxWin → then start the master on the real-time system → scan the network → stop the master → stop LxWin.

The second procedure is for switching the modes (configuration and diagnosis). The user can e.g. start LxWin → start the master → switch to diagnosis. On switching back the user can stop the master and stop LxWin. Or it is also possible not to stop the LxWin for example.

The *Configuration* and *Configuration Mode* circles are the starting points. Then the scripts are called clockwise following the arrows and the red numbers.

5.2.13 Simulator Settings

In this tab, the user can change the settings for the simulator. The tab is only visible when the user uses EC-Simulator EMI or when the Master Unit has an linked simulator unit. The linked simulator unit can be created through the context menu of the master unit, or when the simulator link layer is selected:

**Simulator RAS Port:**

The port which is opened through the simulator link layer

License key:

The license key for the simulator

Slave Settings:**Operation Mode:**

Ignore Download Error

CoE Settings:

Select which CoE should be used in EXI

Register Settings:

Select if register should be in EXI

Starting Position:

Select if slave shall be powered on or off on start

EEPROM Settings:

Select which EEPROM values should be used


The EXI file can be exported through the *Export EXI* button right from the *Export ENI* Button or through the context menu.

5.3 Slave Settings

This section includes slave related settings. The most of all settings will affect the “Slave” section of the ENI.

5.3.1 General

In this tab, the user can change general slave settings like station address or the name of the slave. He has also the possibility to change his predecessor device:



Address

Station Address:

Station address of the slave. By default, the first station address is 1001.

Information

Name:

Name of the slave. By default the following format is used “Slave_N [TYPE]”

Description:

Description of the slave (Read from ESI file)

Vendor:

Name of the vendor the slave

Product Code:

Product Code of the slave

Revision Number:

Revision Number of the slave

ESI File:

Name of the ESI `file` where the description of the slave is stored.
 : file: `ESI files can be managed by using the *ESI-Manager*

Identification Value:

Identification Value of the slave

Ports

Connected Devices:


List of connected devices

Predecessor Device:

Name of the predecessor device. If topology should be changed, please use the *Edit Topology* dialog

5.3.2 Modules

In this tab, the user has can assign modules into the specific slots. He can also change the setting for downloading the slot configuration to the slave:



Connect module to slot (“<<”)

Used for connecting the selected module (from the right list) to the selected slot (from the left list). If the slot is already connected, the module will be inserted and the subsequent modules will be moved (if this is supported from the slave)

Disconnect module from slot (“X”)

Used for disconnecting the selected slot (left list)


Note: The modules can be also connected and disconnected by using the context menu in the project explorer.

5.3.3 PDO Mapping

This tab consists of 2 views:

PDO

In this tab, the user can see the current PDO mappings. For some Slave types the user can activate or deactivate some PDO configurations:



The screenshot shows the 'Device Editor' interface with the 'PDO Mapping' tab selected. The interface is divided into 'Inputs' and 'Outputs' sections. Each section contains a list of PDO mappings with columns for Name, Index, and Bit Length. The 'Inputs' section shows three active mappings (1st, 2nd, and 3rd Transmit PDO mapping) and one excluded mapping (4th Transmit PDO mapping). The 'Outputs' section shows three active mappings (1st, 2nd, and 3rd Receive PDO mapping) and one excluded mapping (4th Receive PDO mapping). At the bottom, there are buttons for 'Download PDO Configuration', 'Add', 'Delete', 'Edit', 'Up', 'Down', and 'Load PDO information'.

Lists of inputs or outputs

Checkbox:

Signals if PDO will be used for the current configuration or not.

Buttons (Expert mode only!)

Add/Delete/Edit:

Used for changing the lists, if it is allowed by the ESI. First the list which should be changed must be selected.

Up/Down:


Moving the selected PDO in the selected list up or down

Load PDO information:


If EC-Engineer is connected to the control system, the user can load the PDO information directly from the slave

Context Menu

Both lists provide a context menu:



If user wants to add or edit a PDO, he will see the following dialog:



General

Name: 1st Transmit PDO mapping

Index: 0x1A00 (Dec | Hex)

Flags

Mandatory

Fixed Content

Virtual PDO

Direction

TxPdo

RxPdo

Optional

Exclude:

- 1A01
- 1A02
- 1A03

Entries

Name	Index	Bit Length	Comment
Status word	0x6041:00	16	
Position actual value	0x6064:00	32	
Torque actual value	0x6077:00	16	
Following error actual value	0x60F4:00	32	

Add Delete Edit Up Down

OK Cancel

General:**Name:**

Name of the PDO

Index:

Index of the PDO (can be entered in hexadecimal or decimal)

Flags:**Mandatory:**

PDO cannot be deleted

Fixed Content:

Content of PDO cannot be changed

Virtual PDO:

PDO has no entries

Direction:**TxPdo:**

Input PDO

RxPdo:

Output PDO

Sync Manager:

Selected the Sync Manager, which should be used (only visible if more than one can be used)


Exclude:

Select the PDOs which cannot be activated if this PDO is activated

Entries:

List of configured PDO entries

If user wants to add a PDO entry, he will see the following dialog:



General

Name: Error code

Comment:

Swapping: None

Settings

Index: 0x603F (Hex) SubIndex: 0 (Dec)

Datatype: UINT Bit Length: 16

Show Base Datatypes:

CoE Object-Dictionary

Index	Name	Type
0x2720	Safety module monitors	UDINT
0x603F	Error code	UINT
0x6040	Controlword	UINT
0x6041	Statusword	UINT
0x6060	Modes of operation	SINT
0x6061	Modes of operation display	SINT
0x6062	Position demand value	DINT

OK Cancel

General**Name:**

Name of the PDO entry

Comment:

Comment of the PDO entry

Swapping:

Swapping mode of the PDO entry

Settings**Index:**

Index of the PDO entry (can be entered in hexadecimal or decimal)

Subindex:

Subindex of the PDO entry (hexadecimal)

Datatype:


List of available datatypes

Bit Length:

Length of the PDO entry in bits

CoE Object-Dictionary (loaded only if Object-Dictionary is supported by slave)

If user wants to edit a PDO entry without a CoeOD, he will see the following dialog:



General

Name:

Name of the PDO entry

Comment:

Comment of the PDO entry

Swapping:

Swapping mode of the PDO entry

FMMU/SM

In this tab, the user can see some information about FMMU and SyncManager:

Device Editor

General
Modules
PDO Mapping
Variables
Advanced Options
Init Commands
CoE Object-Dictionary
Sync Units
Motion

PDO
FMMU/SM

FMMU

No	Type	Logical Start Address	Length	Logical End Bit	Physical Address	Sm	Su
0	Outputs	0x10000004.0	127	7	0x1000	-	-
1	Inputs	0x10000004.0	135	7	0x1600	-	-
2	Mailbox State	0x09000000.2	1	2	0x080D	-	-

SM

No	Type	Start Address	Length	Buffer Mode	Enable
0	Mailbox Outputs	0x1C00	512	1	1
1	Mailbox Inputs	0x1E00	512	1	1
2	Outputs	0x1000	127	3	1
3	Inputs	0x1600	135	3	1

Lists of FMMUs

Available FMMUs comes from the ESI file.

Lists of SyncManagers

Available SyncManagers comes from the ESI file.

5.3.4 Variables

In this tab, the user can see the variables of the slave and if it is allowed he can also add/edit/delete/move variables. Also “Add to watchlist” is possible:

Device Editor

General | Modules | PDO Mapping | **Variables** | Advanced Options | Init Commands | CoE Object-Dictionary | Sync Units | Motion

Variables

Name	Datatype	Master Sync Unit	Offset	Size
Slave_1019 [VIPA 053-1EC00].Inputs.Hardware Interrupt Counter	UDINT	Id 1000: MasterSyncUnit 1000	IN : 38.0	4.0
Slave_1019 [VIPA 053-1EC00].Inputs.Diagnostic Interrupt Counter	UDINT	Id 1000: MasterSyncUnit 1000	IN : 42.0	4.0
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 0	BOOL	Id 1000: MasterSyncUnit 1000	IN : 46.0	0.1
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 1	BOOL	Id 1000: MasterSyncUnit 1000	IN : 46.1	0.1
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 2	BOOL	Id 1000: MasterSyncUnit 1000	IN : 46.2	0.1
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 3	BOOL	Id 1000: MasterSyncUnit 1000	IN : 46.3	0.1
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Status byte	USINT	Id 1000: MasterSyncUnit 1000	IN : 47.0	1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 1	USINT	Id 1000: MasterSyncUnit 1000	IN : 48.0	1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 2	USINT	Id 1000: MasterSyncUnit 1000	IN : 49.0	1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 3	USINT	Id 1000: MasterSyncUnit 1000	IN : 50.0	1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 4	USINT	Id 1000: MasterSyncUnit 1000	IN : 51.0	1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 5	USINT	Id 1000: MasterSyncUnit 1000	IN : 52.0	1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 6	USINT	Id 1000: MasterSyncUnit 1000	IN : 53.0	1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 7	USINT	Id 1000: MasterSyncUnit 1000	IN : 54.0	1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 8	USINT	Id 1000: MasterSyncUnit 1000	IN : 55.0	1.0

Add to watch list

Edit Variable

Move Up Move Down New Edit Delete

New Alias Edit Alias Delete Alias

Lists of Variables

Variables comes from the ESI file or will be generated from the configurator.

Buttons

New/Edit/Delete:

Used for changing the list.

Up/Down:

Moving the selected variable up or down

New/Edit/Delete Alias:

Used for changing alias variables

If user wants to add a variable, he will see the following dialog:

The dialog box titled "Add Variable" contains the following fields:

- Group:** A dropdown menu with "2nd Transmit PDO mapping" selected.
- Datatype:** A dropdown menu with "ARRAY [0..15] OF BYTE" selected.
- Count:** A numeric input field with "1" and up/down arrow buttons.
- Combine:** An unchecked checkbox.

Buttons for "OK" and "Cancel" are located at the bottom.

Options

Group:

List of possible groups, where the new variable should be added

Datatype:

List of possible datatypes of the new variable


Count:

Number of variables, which should be added

Combie:


Combines all variables to an array

If user wants to edit a variable, he will see the following dialog:

**Options****Name:**

Name of the variable, which can be changed from the user

If user wants split a variable into multiple parts to build e.g. a structure, he can add an alias to a variable. In that case he will see the following dialog:

**Options****Name:**

Name of the alias


Datatype:

List of possible datatypes of the new alias

Offset:

Bit offset of the alias

If user wants to edit a alias, he will see the following dialog:




Options

Name:

Name of the alias, which can be changed from the user

5.3.5 EtherCAT P

In this tab, the user can configure the selected EtherCAT P slave. The Tab is only visible when the selected slave is an EtherCAT P slave:

**Wire Gauge:**

The wire type of the input cable

Wire Length:

The wire length of the input cable

Us:

System Voltage

**The system voltage shall supply all internal and externally connected types of sensors and inputs.
All bus system relevant parts of the device shall completely be powered by the Us.**

Actual Voltage:

The actual voltage at the slave

Min Voltage:

The min Voltage the slave needs. Value is from ESI but also editable.

Load:

The Load which is externally needed.

Load Type:

The Load Type of the externally needed load

Up:

Peripheral Voltage:

Up is used to supply internal and externally connected actuators and outputs.

Actual Voltage:

The actual voltage for the outputs

Min Voltage:

The min Voltage the slave needs. Value is from ESI but also editable.

Load:

The Load which is externally needed.

Load Type:

The Load Type of the externally needed load

Load Types:

Sw Regulator in Watt LDO in Ampere Resistor in Ohm

5.3.6 Advanced Slave Options (Expert)

In this tab, the user can change advanced options of the slave:

Device Editor

General | PDO Mapping | Variables | Group | **Advanced Options** | Distributed Clocks | Init Commands | CoE Object-Dictionary | Sync Units

Startup Checking

Check Vendor ID
 Check Product Code
 Check Revision Number
 ==
 Check Serial Number

Identification Checking

Check Identification
 0 Hex Write to EEPROM
 Select Local Address
 0x0012 Dec Hex

Process Data Mode

Disable LRW

Overwrite Watchdog

Set Multiplier (Reg.: 0x400): 2498
 Set PDI Watchdog (Reg.: 0x410): 1000
 Set SM Watchdog (Reg.: 0x420): 1000

Distributed Clocks

Potential Reference Clock

Timeouts

SDO Access: 0 [ms]
 Init->Pre-Op/Init->Bootstrap: 3000 [ms]
 Pre-Op->Safe-Op/Safe-Op->Op: 10000 [ms]
 Back to Pre-Op, Init: 5000 [ms]
 Op->Safe-Op: 200 [ms]

Mailbox Mode

Cyclic
 State Change 10 [ms]

Overwrite Mailbox Size

Output Size: 128 [bytes]
 Input Size: 128 [bytes]

Process Data Sync Manager Mode

Default
 Buffered (3 buffer mode)
 Mailbox (Single buffer mode)

Startup Checking

Master will check the Vendor ID, Product code, Revision number if the state machine changes from INIT to PREOP of the slave. Revision number can be verified by six ways:

- “==” -> HI word is equal, LO word is equal
- “>=” -> HI word is equal or greater, LO word is equal or greater
- “LW ==” -> HI word is equal
- “LW ==, HW >=” -> LO word is equal, HI word is equal or greater
- “HW ==” -> LO word is equal
- “HW ==, LW >=” -> HI word is equal, LO word is equal or greater

Identification Checking

If ‘Check Identification is selected, the Identification Value of the slave is checked. In the ‘Select Local Address’ Box is the register of the Identification Value.

Process Data Mode

Disable LRW: Determines whether LRD/LWR command or the LRW command is used for accessing process data. Cable redundancy needs LRD/LWR, Slave-to-slave-copy needs LRW.

Watchdog

Set Multiplier:

Writes the configured value to the corresponding slave register: 0x0400

Set PDI Watchdog:

Writes the configured value to the corresponding slave register: 0x0410 (0 = Watchdog is disabled)

Set SM Watchdog:

Writes the configured value to the corresponding slave register: 0x0420 (0 = Watchdog is disabled)

Distributed Clocks**Potential Reference Clock: Set to use slave as a potential reference clock**

- This might be useful, if e.g. a hot connect slave, which is used as reference clock, was disconnected from the network
- In that case the EC-Master searches for the first potential reference clock
- If no potential reference clock slave was found, the first DC slave will be used

Timeouts**SDO Access:**

Internal master timeout which is used for accessing the SDO (0 = Use internal default value of the master)

Init -> PreOp:

Internal master timeout which is used for changing slave state

Pre-Op -> Save-Op or Safe-Op ->Op:

Internal master timeout which is used for changing slave state

Back to Pre-Op, Init:

Internal master timeout which is used for changing slave state

Op -> Safe-Op:

Internal master timeout which is used for changing slave state

Mailbox Mode**Cyclic:**

Interval in milliseconds within the input mailbox will be read (polling mode)

State Change:

The input mailbox will be read only if the status bit is set

Overwrite Mailbox Size**Output Size:**

Overwrites mailbox output size

Input Size:

Overwrites mailbox input size

Process Data Sync Manager Mode**Default:**

Uses sync manager mode from ESI file

Buffered (3 buffer mode):

Enables 3 buffer mode

Mailbox (Single buffer mode):

Enables single buffer mode

5.3.7 (Hot Connect) Groups

In this tab, the user can choose if this group has a fixed offset in the process data image or if this group is a hot connect group:

The screenshot shows the 'Device Editor' window with the 'Group' tab selected. The configuration is as follows:

Section	Property	Value
General	MSU Id	10
	Name	Group 0
Pinned Group	Input Offset (byte)	0
	Output Offset (byte)	0
Hot Connect Group	Identification Offset	0x0012
	Identification Value	0
	Position in Topology	Fixed to 'Class-A Master'
	Hot Connect Group (checkbox)	<input type="checkbox"/>

Note: Tab is only visible if slave is the first member of a group.

General

MSU Id:
Generated Master Sync Unit Id

Name:
Name of the group

Pinned Group

Input Offset:
Fixed input offset of the group in the process data image in bytes

Output Offset:
Fixed output offset of the group in the process data image in bytes


Hot Connect Group

Identification Offset:
Register offset where the identification can be read from the slave


Identification Value:

Hardware identification value or configured station alias address can be used. For more information about the configured station alias address, see [EEPROM \(Expert\)](#)

A new group can be created by selecting all slaves (by using the **SHIFT** key or the **CTRL** key), open the context menu and select **Create Group** in the project explorer:





The new group can be modified by selecting the head slave of this group and open tag **Group**:




On this tab, the user can pin this group of slaves to a specific offset in the process image and / or build a hot connect group. If we do this, in that case this will generate an invalid topology error, because a normal slave is still connected to this hot connected, which is not allowed.

In that case we can use “cut & paste” to solve this issue by connecting this hot connect group to the end of the slaves:



Now, we have a hot connect group which is connectable only to slave 1011. If we want to connect this group to any slave on the network, we have to detach the group:




A group can be deleted by selecting the head slave of this group, open the context menu and select “Remove Group” in the project explorer (only attached HC groups can be deleted).

Possible group related error messages:

- Detached group can not be attached to the old position in the tree (e.g. previous slaves was deleted or disabled) the head slave of the group will be reported as “not connected”. In that case the user can connect the head slave by using “cut” and “paste”.
- Invalid topology from slave (fixed HC group on master) was displayed: this means that the first HC group which is connected to the master should be detached, because this is not valid in the ENI file
- Invalid topology from slave (slave connected to HC group) was displayed: this means that a normal slave is connected to a hot connect group and should be also moved also into a hot connect group or moved to another position in the tree

5.3.8 Ethernet (EoE)

In this tab, the user can activate EoE support and change the settings:



Device Editor

General | PDO Mapping | Variables | **Ethernet** | Advanced Options | Distributed Clocks | Init Commands | Sync Units

Ethernet

Virtual MAC address: 02 00 00 00 03 EA Auto

Time Stamp Requested:

Port Mode: Switch Port IP Port

Overwrite IP Settings

IP Address: 1 . 0 . 0 . 0

Subnet Mask: 1 . 0 . 0 . 0

Default Gateway: 1 . 0 . 0 . 0

DNS Server: 1 . 0 . 0 . 0

DNS Name:

Ethernet (activates EoE support):

Virtual MAC address:

Virtual MAC address. If “Auto” is checked, the Virtual MAC address will be generated from the Station Address, e.g. Station Address is “1010” (= 0x03F2), will generate the Virtual MAC address: “01 00 00 00 03 F2”

Time Stamp Requested:

Slave will response with the exact send time and the same Frame Number and he should response as soon as possible

Port Mode:


Slave can run in “Switch Port” or in “IP Port” mode

Override IP Settings:

All IP settings will be overwritten from master like IP Address, Subnet Mask, Default Gateway, DNS Server and DNS Name.

5.3.9 Distributed Clock (Expert)

In this tab, the user can change distributed clock related settings:



Reference Clock

Operation Mode:

Selectable DC operation modes. The modes cannot be edited.

Sync Unit Cycle:

Base interval in microseconds which will be used from master (see *Master*)

Overwrite Mode:

Overwrites the settings of the selected operation mode (might be necessary, if the slave doesn't offer the right operation mode)

Sync Units

Sync Unit 0

Cycle Time

Sync Unit Cycle:

Unit is synchronized relative to the Unit Cycle

User defined:

Unit has its own interval

Shift Time

Unit is adjusted by the shift time

Sync Unit 1

Cycle Time

Sync Unit Cycle:

Unit is synchronized relative to the Unit Cycle

Sync 0 Cycle:

Unit is synchronized relative to the first Sync Unit

User defined:

Unit has its own interval

Shift Time

Unit is adjusted by the shift time

5.3.10 Init Commands (Expert)

In this tab, the user can view the current configured init commands and if it is allowed he can also add/edit/delete init commands:

The screenshot shows the 'Device Editor' window with the 'Init Commands' tab active. The table below represents the data shown in the interface:

Transition	Protocol	Index	Value	Comment	Access
Pre-Op->Safe-Op	CoE	0x1C12:000	0	clear sm pdos (0x1C12)	RO
Pre-Op->Safe-Op	CoE	0x1C13:000	0	clear sm pdos (0x1C13)	RO
Pre-Op->Safe-Op	CoE	0x1A00:000	0	clear pdo 0x1A00 entries	RO
Pre-Op->Safe-Op	CoE	0x1A00:001	1614872592	download pdo 0x1A00 entry	RO
Pre-Op->Safe-Op	CoE	0x1A00:002	1617166368	download pdo 0x1A00 entry	RO
Pre-Op->Safe-Op	CoE	0x1A00:003	1618411536	download pdo 0x1A00 entry	RO
Pre-Op->Safe-Op	CoE	0x1A00:004	1626603552	download pdo 0x1A00 entry	RO
Pre-Op->Safe-Op	CoE	0x1A00:005	1616969736	download pdo 0x1A00 entry	RO
Pre-Op->Safe-Op	CoE	0x1A00:006	8	download pdo 0x1A00 entry	RO
Pre-Op->Safe-Op	CoE	0x1A00:007	1622736912	download pdo 0x1A00 entry	RO
Pre-Op->Safe-Op	CoE	0x1A00:008	1622802464	download pdo 0x1A00 entry	RO
Pre-Op->Safe-Op	CoE	0x1A00:000	8	download pdo 0x1A00 entry count	RO
Pre-Op->Safe-Op	CoE	0x1A01:000	0	clear pdo 0x1A01 entries	RO
Pre-Op->Safe-Op	CoE	0x1A01:001	1614872592	download pdo 0x1A01 entry	RO
Pre-Op->Safe-Op	CoE	0x1A01:002	1617166368	download pdo 0x1A01 entry	RO

Below the table, there is an 'Edit Value' section with a text input field containing '0' and a 'Hex' checkbox. At the bottom, the 'Edit Init Command' section contains buttons for 'Move Up', 'Move Down', 'New', 'Copy', 'Edit', and 'Delete'.

Lists of Init Commands

Init Commands comes from the ESI file or will be generated from the configurator. The “Access” column tells the user if this Init Command can be edited (RW = Read/Write) or not (RO = Read-Only).

Buttons


New/Copy/Edit/Delete:

Used for changing the list

Up/Down:

Moving the selected Init Command up or down

At the moment only Init Commands of the CoE- and SoE- Protocol can be added or changed. If the user wants to do this he will see the following dialog (CoE):



General

Index:

CoE-Index of the Init Command

SubIndex:

CoE-SubIndex of the Init Command

Value:

Value of the Init Command, which should be written in the chose transition (only available if direction is set to “Download”). If type of value is unknown, the hex format must be used like “00 11 22 33 ...”.

Comment:

Comment of the Init Command

Transition

Determines in which transition the Init Command will be executed

Further Settings

Determines if the complete SDO object should be written/read

Direction

Determines the direction of the Init Command


Download:

Writes value to slave

Upload:

Reads value from slave (e.g. necessary if value must be confirmed)

For SoE the user will see the following dialog:



General

Index:

SoE Idn of the Init Command

Channel:

The channel of the Init Command

Value:

Value of the Init Command

Comment:


Comment of the Init Command

Transition

Determines in which transition the Init Command will be executed

5.3.11 CoE Object-Dictionary (Expert)

In this tab, the user can see and edit the offline CoE object dictionary.



The screenshot shows the 'CoE Object-Dictionary' tab in the Device Editor. The table below represents the data shown in the interface.

Index	Name	Value	Type	Flags
0x1000	Device Type	131474 (0x20192)	UDINT	---- (RO RO RO)
0x1001	Error Register	-	USINT	---- (RO RO RO)
0x1008	Manufacturer Device Name	-	STRING(1)	---- (RO RO RO)
0x100A	Manufacturer Software Version	-	STRING(1)	---- (RO RO RO)
▶ 0x1010	Store Parameters	-	USINT	---- (RO RO RO)
▶ 0x1011	Restore Default Parameters	-	USINT	---- (RO RO RO)
▶ 0x1018	Identity Object	-	USINT	---- (RO RO RO)
▶ 0x10F1	Sync Error Settings	-	USINT	---- (RO RO RO)
▶ 0x1600	1st receive PDO Mapping	-	USINT	---- (RW RW RW)
▶ 0x1601	2nd receive PDO Mapping	-	USINT	---- (RW RW RW)
▶ 0x1602	3rd receive PDO Mapping	-	USINT	---- (RW RW RW)
▶ 0x1603	4th receive PDO Mapping	-	USINT	---- (RW RW RW)
▶ 0x1A00	1st transmit PDO Mapping	-	USINT	---- (RW RW RW)
▶ 0x1A01	2nd transmit PDO Mapping	-	USINT	---- (RW RW RW)
▶ 0x1A02	3rd transmit PDO Mapping	-	USINT	---- (RW RW RW)
▶ 0x1A03	4th transmit PDO Mapping	-	USINT	---- (RW RW RW)

Below the table, there is an 'Edit Value' section with a text input field containing '0', and buttons for 'Dec', 'Hex', 'Write', and 'Reset'.

Lists of CoE Object-Dictionary entries

- Entries comes from the ESI file or will be generated from the configurator.
- The “Flags” column tells the user if this entry is an PDO entry and if it can be edited
 - “AA BB C D (EE FF GG)”
 - AA = Mapping as RX PDO or not
 - BB = Mapping as TX PDO or not

- C = Backup Flag
- D = Settings Flag
- EE = Access rights for PreOp (RO, WO, RW)
- FF = Access rights for SafeOp (RO, WO, RW)
- GG = Access rights for Op (RO, WO, RW)

Buttons

Update:


Changes the selected entry

Reset:

Resets the selected entry to ESI default

5.3.12 SoE Object-Dictionary (Expert)

In this tab, the user can see and edit the offline SoE object dictionary.



Device Editor

General | PDO Mapping | Variables | Advanced Options | Distributed Clocks | Init Commands | SoE-Object-Dictionary | Sync Units | Motion

Values

Index	Name	Value	Channel
S-0-0001	Control unit cycle time (TNcyc)	1000 (0x3E8)	A
S-0-0002	Communication cycle time (tSync)	1000 (0x3E8)	
S-0-0007	Feedback acquisition capture point (t4)	-	
S-0-0011	Class 1 diagnostic (C1D)	-	
S-0-0012	Class 2 diagnostic (C2D)	-	
S-0-0015	Telegram type	7 (0x07)	
S-0-0016	Configuration list of AT	(list)	
S-0-0017	IDN-list of all operation data	(list)	
S-0-0018	IDN-list of operation data for CP2	(list)	
S-0-0019	IDN-list of operation data for CP3	(list)	
S-0-0020	IDN-list of operation data for CP4	(list)	
S-0-0021	IDN-list of invalid operation data for CP2	(list)	
S-0-0022	IDN-list of invalid operation data for CP3	(list)	
S-0-0024	Configuration list of MDT	(list)	
S-0-0025	IDN-list of all procedure commands	(list)	
S-0-0029	MDT error counter	-	

Edit Value

Value: Dec Hex Write Reset

Lists of SoE Object-Dictionary entries

Entries comes from the ESI file

Buttons

Update:

Changes the selected entry

Reset:

Resets the selected entry to ESI default

5.3.13 Sync Units (Expert)

In this tab, the user can assign a slave sync unit to a specific master sync unit by using the combobox column “Master Sync Unit” (only visible if user has defined additional master sync units).

Name	Input Size [bytes]	Output Size [bytes]	Master Sync Unit
▼ SyncUnit 0	135.0	127.0	Id 1000: MasterSyncUnit 1000
Slave_1019 [VIPA 053-1EC00].Inputs.Hardware Interrupt Counter			UDINT IN : 38.0 4.0
Slave_1019 [VIPA 053-1EC00].Inputs.Diagnostic Interrupt Counter			UDINT IN : 42.0 4.0
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 0			BOOL IN : 46.0 0.1
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 1			BOOL IN : 46.1 0.1
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 2			BOOL IN : 46.2 0.1
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 3			BOOL IN : 46.3 0.1
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Status byte			USINT IN : 47.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 1			USINT IN : 48.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 2			USINT IN : 49.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 3			USINT IN : 50.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 4			USINT IN : 51.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 5			USINT IN : 52.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 6			USINT IN : 53.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 7			USINT IN : 54.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 8			USINT IN : 55.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 9			USINT IN : 56.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 10			USINT IN : 57.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 11			USINT IN : 58.0 1.0
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 12			USINT IN : 59.0 1.0

5.3.14 Slave Specific Tabs (Expert)

Some slaves need special configuration options. If this is necessary we display a slave specific tab.

Important: At first “Activate” has to be set, to activate the automatism for generating PDOs and Init Commands.

This tab will be displayed for the following slaves:

EL6731-0010 PROFIBUS DP Slave

General:

Device Editor

General | PDO Mapping | Variables | Advanced Options | Init Commands | CoE Object-Dictionary | Sync Units | Motion | EL6731-0010

General Modules

Values

Name			
▼ General			
Name	Value	Type	Access
Activate	0	INT32	RW
▼ DP Slave Parameter Set			
Name	Value	Type	Access
Station Address	0	UINT32	RW
Device Type	2399	UINT32	RW
Change of DP inputs after DP fault	0	INT32	RW

Edit Value

Value: Dec Hex Write

Activate: Activates the automatism for generating PDOs and Init Commands

DP Slave Parameter Set


Station Address:

DP station address of the DP slave (permitted values: 0-125)

Device Type:

DP Ident Number of the DP slave

Modules:



Connect modules to slot (“<<”)

Used for connecting the selected modules (from the right list) to the selected slot (from the left list).

Disconnect module from slot (“X”)

Used for disconnecting the selected slot (left list)

EL6631-0010 PROFINET IO Device

General:

Device Editor

General | PDO Mapping | Variables | Advanced Options | Init Commands | CoE Object-Dictionary | Sync Units | Motion | EL6631-0010

General Modules

Values

Name			
▼ General			
Name	Value	Type	Access
Activate	0	INT32	RW
▼ IO Device Parameter Set			
Name	Value	Type	Access
Module DAP Version	0	UINT32	RW
Station Name		STRING	RW
IP Address		STRING	RW
Subnet		STRING	RW
Gateway		STRING	RW

Edit Value

Value:

Activate: Activates the automatism for generating PDOs and Init Commands

IO Device Parameter Set


Module DAP Version:

Module DAP version of the DP slave (0 = Auto, 1 = V2.0, 2 = V2.25, 3 = V2.3, at least FW 02, 4 = V2.31, at least FW 03, 5 = V2.32, at least FW 08, 6 = V2.33, at least FW 10, 7 = V2.33, at least FW 14)

Station Name:

Station name of the DP slave (max: 240 chars)

Modules:



Connect module to slot (“<<”)

Used for connecting the selected module (from the right list) to the selected slot (from the left list).

Disconnect module from slot (“X”)

Used for disconnecting the selected slot (left list)

K-bus Coupler / IP Link Coupler

Supported devices:

K-bus Coupler

- BK1120
- BK1150
- BK1250

IP Link Coupler

- IL2300-B110
- IL2301-B110
- IL2302-B110

General:

Activate:

Activates the automatism for generating PDOs and Init Commands

Check Terminals at Startup:

Activates the automatism for checking terminals at startup

Device Editor

General | PDO Mapping | Variables | Advanced Options | Init Commands | Sync Units | Motion | BK1120

General Modules

Values

General			
Name	Value	Type	Access
Activate	0	INT32	RW
Check Terminals at Startup	0	INT32	RW

Edit Value

Value: Dec Hex Write

Terminals:

Device Editor

General | PDO Mapping | Variables | Advanced Options | Init Commands | Sync Units | Motion | BK1120

General Modules

Assign the modules

- 000: Terminal [--]
- 001: Terminal [--]
- 002: Terminal [--]
- 003: Terminal [--]
- 004: Terminal [--]
- 005: Terminal [--]
- 006: Terminal [--]
- 007: Terminal [--]
- 008: Terminal [--]
- 009: Terminal [--]
- 010: Terminal [--]
- 011: Terminal [--]
- 012: Terminal [--]
- 013: Terminal [--]
- 014: Terminal [--]
- 015: Terminal [--]
- 016: Terminal [--]
- 017: Terminal [--]
- 018: Terminal [--]
- 019: Terminal [--]
- 020: Terminal [--]
- 021: Terminal [--]

- Virtual Terminals (CP1xxx)
 - CP9940-0001 40 Ch. Input
 - CPx9xx-4 LEDs/Buttons
 - CPx9xx-8 LEDs/Buttons
 - CPx9xx-12 LEDs/Buttons
 - CPx9xx-16 LEDs/Buttons
 - CPx9xx-20 LEDs/Buttons
 - CPx9xx-24 LEDs/Buttons
 - CPx9xx-28 LEDs/Buttons
 - CPx9xx-3-2 LEDs/Buttons/Inputs
 - CPx9xx-4-2 LEDs/Buttons/Inputs
 - CPx9xx-E-Stop
- Digital Input Terminals (KL1xxx)
 - KL 1002, 2 Ch. Input (24V, 3.0ms)
 - KL 1012, 2 Ch. Input (24V, 0.2ms)
 - KL 1032, 2 Ch. Input (48V, 3.0ms)
 - KL 1052, 2 Ch. Input +/- (24V, 3.0ms)
 - KL 1104, 4 Ch. Input (24V, 3.0ms)
 - KL 1114, 4 Ch. Input (24V, 0.2ms)
 - KL 1124, 4 Ch. Input (5V, 0.2ms)
 - KL 1154, 4 Ch. Input +/- (24V, 3.0ms)
 - KL 1164, 4 Ch. Input +/- (24V, 0.2ms)

Scan 'KBUS' Modules

Connect terminals to slot (“<<”)

Used for connecting the selected terminal (from the right list) to the selected slot (from the left list).


Disconnect terminals from slot (“X”)

Used for disconnecting the selected slot (left list)

5.3.15 IO-Link

In this tab, the user can configure the IO-Link terminal EL6224, EP6224 and EP(P)6228. He can add different devices to the ports (IODD). The user can see 4 or 8 ports. Depends on the configured slave.


Please be careful when using the EP(P)6228 that there are no double assignments through the Modules-Tab:



5.3.16 Profibus Master (EL6731)

In this tab, the user can configure the Profibus Master EL6731. New Profibus modules can be added in the tree. Right click and then ‘Append module’.

Each module has an own EL6731 tab with settings and the possibility to load a GSD file. After the GSD file was loaded the user gets also PRM data settings and the possibility to add a submodule (e.g. K-Bus) via the tree.



5.3.17 CANopen Master (EL6751)

In this tab, the user can configure the CANopen Master EL6751. He can add Modules, PDOs, SDOs and variables by clicking the right mouse button. To activate the master, the user have to go to the general settings of the EL6751 entry, and set activated to ‘1’. If activated is ‘1’ all init commands and PDOs will be activated automatically.

Also the user can rename and delete modules, PDOs, SDOs, and variables:

Device Editor

General | Modules | PDO Mapping | Variables | Advanced Options | Distributed Clocks | Init Commands | CoE Object-Dictionary | Sync Units | Motion | EL6751

Filter

EL6751	Settings		
CANopen Module 1			
CANopen Module 2			

Settings

Name	Value	Type
General		
Name		
Activate	0	BOOL
Control	0	BOOL
CAN Bus Parameter Set		
Name		
CAN Bus Parameter Set	17	UINT32
Master Node Address	127	UINT32
Speed	2	UINT32

Edit Value

Value: Dec Hex Write

5.3.18 CANopen Slave (EL6751-0010)

In this tab, the user can configure the CANopen Slave EL675-0010. He can add PDOs and variables by clicking the right mouse button. To activate the gateway, the user have to go to the general settings of the EL6751-0010 entry, and set activated to '1'. If activated is '1' all init commands and PDOs will be activated automatically.

Also the user can rename and delete PDOs and variables:

Device Editor

General | PDO Mapping | Variables | Advanced Options | Init Commands | CoE Object-Dictionary | Sync Units | Motion | EL6751-0010

Filter

EL6751-0010

Settings

TxPDOs

RxPDOs

Settings

Name	Value	Type
General		
Name		
Activate	1	BOOL
Settings		
Name		
Node Id	1	UINT32
Baudrate	2	UINT32
Cycle Time	1000000	UINT32
Cliff Time	600000	UINT32

Edit Value

Value: Write

5.3.19 Motion (Motion Mode only)

On this tab the user can change the and activate the axis for the motion. The settings are used in the `xml` file which can be exported from the master motion tab, to configure the Demo Motion:

Device Editor


General | Modules | PDO Mapping | Variables | Advanced Options | Init Commands | CoE Object-Dictionary | Sync Units | Motion

EcMasterDemoMotion Config Slave Settings

	Axis 1 <input checked="" type="checkbox"/>	Axis 2 <input type="checkbox"/>
Mode of Operation	8	8
Increments per mm	1000	1000
Increment Factor	0	0
Controlword Object	0x6040 Dec Hex 0x00 Dec Hex	0x6840 Dec Hex 0x00 Dec Hex
Statusword Object	0x6041 Dec Hex 0x00 Dec Hex	0x6841 Dec Hex 0x00 Dec Hex
Position Actual Value Object	0x6064 Dec Hex 0x00 Dec Hex	0x6864 Dec Hex 0x00 Dec Hex
Target Position Object	0x607A Dec Hex 0x00 Dec Hex	0x687A Dec Hex 0x00 Dec Hex
Target Velocity Object	0x60FF Dec Hex 0x00 Dec Hex	0x68FF Dec Hex 0x00 Dec Hex
Modes of operation Object	0x6060 Dec Hex 0x00 Dec Hex	0x6860 Dec Hex 0x00 Dec Hex

5.3.20 Simulation Settings

On this tab the user can change the simulator settings for the slave:

**Application Name:**

The application name for the EXI file

Ignore Download Error:

Ignores errors on download

Starting Position**Power Off:**

Select if slave should be powered on or off on start

Custom previous port:

manipulate the topology

CoE Tab

Device Editor

General | PDO Mapping | Variables | Advanced Options | Distributed Clocks | Init Commands | CoE Object-Dictionary | Sync Units | Motion | Simulator

General CoE EEPROM Register

CoE Settings

Use generic Object Dictionary Create from ESI Load from Slave

Index	Name	Value	Type	Flags
0x1000	Device Type	131474 (0x20192)	UDINT	-- -- -- (RO RO RO)
0x1001	Error Register	0 (0x00)	USINT	-- -- -- (RO RO RO)
0x1008	Manufacturer Device Name		STRING(1)	-- -- -- (RO RO RO)
0x100A	Manufacturer Software Version		STRING(1)	-- -- -- (RO RO RO)
▶ 0x1010	Store Parameters	0 (0x00)	USINT	-- -- -- (RO RO RO)
▶ 0x1011	Restore Default Parameters	0 (0x00)	USINT	-- -- -- (RO RO RO)
▶ 0x1018	Identity Object	0 (0x00)	USINT	-- -- -- (RO RO RO)
▶ 0x10F1	Sync Error Settings	0 (0x00)	USINT	-- -- -- (RO RO RO)
▶ 0x1600	1st receive PDO Mapping	0 (0x00)	USINT	-- -- -- (RW RW RW)
▶ 0x1601	2nd receive PDO Mapping	0 (0x00)	USINT	-- -- -- (RW RW RW)
▶ 0x1602	3rd receive PDO Mapping	0 (0x00)	USINT	-- -- -- (RW RW RW)
▶ 0x1603	4th receive PDO Mapping	0 (0x00)	USINT	-- -- -- (RW RW RW)
▶ 0x1A00	1st transmit PDO Mapping	0 (0x00)	USINT	-- -- -- (RW RW RW)
▶ 0x1A01	2nd transmit PDO Mapping	0 (0x00)	USINT	-- -- -- (RW RW RW)
▶ 0x1A02	3rd transmit PDO Mapping	0 (0x00)	USINT	-- -- -- (RW RW RW)

Edit Value

Value: Dec Hex Write

The simulated CoE can be changed here.

EEPROM Tab

Device Editor

General | PDO Mapping | Variables | Advanced Options | Distributed Clocks | Init Commands | CoE Object-Dictionary | Sync Units | Motion | Simulator

General CoE EEPROM Register

EEPROM Settings

Use ESI EEPROM Create from ESI Load from Slave

Index	Name	Value	Type
0x0000	PDI Control	6 (0x0006)	UINT
0x0001	PDI Configuration	60929 (0xEE01)	UINT
0x0002	Pulse Length of SYNC Signals	1000 (0x03E8)	UINT
0x0003	Extended PDI Configuration	0 (0x0000)	UINT
0x0004	Configured Station Alias	0 (0x0000)	UINT
0x0005	Reserved	0 (0x00000000)	UDINT
0x0007	Checksum	61 (0x003D)	UINT
0x0008	Vendor ID	1337 (0x0000539)	UDINT
0x000A	Product Code	35651585 (0x2200001)	UDINT
0x000C	Revision Number	196613 (0x0030005)	UDINT
0x000E	Serial Number	0 (0x00000000)	UDINT
0x0010	Execution Delay	0 (0x0000)	UINT
0x0011	Port0 Delay	0 (0x0000)	UINT
0x0012	Port1 Delay	0 (0x0000)	UINT
0x0013	Reserved	0 (0x0000)	UINT

Edit EEPROM Value

Value: Dec Hex Write

The simulated EEPROM can be changed here.

Register Tab

Device Editor

General | PDO Mapping | Variables | Advanced Options | Init Commands | CoE Object-Dictionary | Sync Units | Motion | Simulator

General CoE EEPROM Register

Register Settings

Use default register values Load from Slave

Index	Name	Value	Type
▶ 0x0000	Type	1 (0x01)	USINT
▶ 0x0001	Revision	1 (0x01)	USINT
▶ 0x0002	Build	12 (0x000C)	UINT
▶ 0x0004	FMMUs supported	2 (0x02)	USINT
▶ 0x0005	SyncManagers supported	4 (0x04)	USINT
▶ 0x0006	RAM Size	4 (0x04)	USINT
▶ 0x0007	Port Descriptor	0 (0x00)	USINT
▶ 0x0008	ESC Features supported	0 (0x0000)	UINT
▶ 0x0010	Configured Station Address	1013 (0x03F5)	UINT
▶ 0x0012	Configured Station Alias	0 (0x0000)	UINT
▶ 0x0020	Write Register Enable	0 (0x00)	USINT
▶ 0x0021	Write Register Protection	0 (0x00)	USINT
▶ 0x0030	ESC Write Enable	0 (0x00)	USINT
▶ 0x0031	ESC Write Protection	0 (0x00)	USINT
▶ 0x0040	ESC Reset ECAT	0 (0x00)	USINT

Edit Register

Value: Dec Hex Write

The simulated Registers can be changed here.

5.4 Export ENI

To run the EC-Master you basically need an EtherCAT-Network-Information (ENI) file to initialize and control an EtherCAT network. After configuring the EtherCAT network with EC-Engineer, you can export this ENI file and copy it on the control system to run the EC-Master.

Note: The EtherCAT-Network-Information (ENI) File will be generated according to ETG.2100 standard V1.0.1

5.5 Export EXI

To run the EC-Simulator you basically need an ENI or better an EXI file to simulate an EtherCAT network. After configuring the EtherCAT network with EC-Engineer, you can export this EXI file and use it to start the EC-Simulator.

6 Diagnosis Mode

6.1 Overview


EC-Engineer is also a diagnosis application specifically developed to analyze EtherCAT networks that are controlled by the EC-Master. Automated control systems usually require high availability of the whole system. Due to the rough industrial environment this is often hardly to achieve.

If high availability shall be guaranteed for an automated control system it is important to verify and maintain the field bus. Using EC-Engineer it is possible to take a look into the “health” of the EtherCAT system. Detection of signs of system degradation prior to running into a system failure will be of great benefit. In that case it is possible to exchange the problematic components (cables, slave devices).

Many aspects of diagnosis are covered by the EC-Engineer:

- Useful for setting up the system
- System analysis and maintenance
- Error detection
- Documentation

After switching into diagnosis mode of EC-Engineer, the user will see this page:



The screenshot displays the EC-Engineer software interface in Diagnosis Mode. The interface is divided into several sections:

- Project Explorer:** Shows a tree view of the system components, including a Class-A Master and 20 slaves (Slave_1001 to Slave_1020).
- Device Editor:** Displays the configuration and status of the selected slave. It includes tabs for General, Process Data Image, Watch list, Performance, Trace Data, CoE Object-Dictionary, and History.
- State Machine:** Shows the current state (Op) and requested state (Op) of the slave. It also includes options for Change State (Init, Pre-Op, Safe-Op, Op).
- Information:** Provides details about the slave, such as Master Version (3.2.0.3), Number of found slaves (26), Number of slaves in configuration (26), Number of DC slaves (4), DC in-sync (Yes), Topology Ok (Yes), Link Connected (Yes), and Slaves in Master State (Yes).
- Frame Counter:** Shows statistics for frame transmission, including Sent frames (309292), Lost frames (27), Cyclic frames (241970), and Acyclic frames (67322).
- Memory Usage:** Displays the current memory usage (860 kB) and maximum memory usage (861 kB).
- Short Info:** Provides a summary of the selected slave, including Name (Class-A Master), Description (EtherCAT Master Unit (Class A)), and Vendor (acontis technologies GmbH).
- Messages:** A section for displaying system messages, currently empty.
- Status Bar:** Shows the current state (State: ●●●) and mode (Mode: DIAGNOSIS | EXPERT).

6.2 Master

This section shows the current “health” state of the master and helps the user to analyze master related problems.

6.2.1 General (Master)

In this tab, the user can see and change the current state of the state machine of the master. He has also an overview over the current “health” state of his EtherCAT network:

The screenshot shows the 'Device Editor' window with the 'General' tab selected. The 'State Machine' section contains fields for 'Current State' and 'Requested State', both set to 'Op', and a 'Change State' button with options for 'Init', 'Bootstrap', 'Pre-Op', 'Safe-Op', and 'Op'. The 'Information' section lists various network parameters: Master Version (3.2.0.3), Number of found slaves (26), Number of slaves in configuration (26), Number of DC slaves (4), DC in-sync (Yes), Topology Ok (Yes), Link Connected (Yes), and Slaves in Master State (Yes). The 'Frame Counter' section shows Sent frames (101094), Lost frames (3), Cyclic frames (73520), and Acyclic frames (27574), with a 'Clear counters' button. The 'Memory Usage' section shows Current [kB] (860) and Max [kB] (861).

State Machine

Current State:

Current state of the master

Requested State:

Requested state of the master

Change State:

Master can reach the states INIT, PRE-OP, SAFE-OP and OP.

Information

Master version:

Version number of the running master

Number of found slaves:

Number of slaves, which were found from master on the network

Number of slaves in configuration:

Number of slaves, which are configured in the ENI file

Number of DC slaves:

Number of slaves with DC support, which were found from master on the network

DC in-sync:

Signals that all slaves with DC support are correctly synchronized or not. If not all slaves are correctly synchronized, please refer the *Message Window* for more information.

Topology OK:

Signals that topology is “okay” or not. If topology is not “okay”, you have a mismatch between the configured bus and the currently connected bus. Please open the ‘Network Mismatch Analyzer’ (Menu Network Network Mismatch Analyzer) to solve the problem.

Link Connected:

Signals the link is connected.

Slaves in Master State:

Signals that all slaves are in master state.

Frame Counter**Sent frames:**

Number of sent frames

Lost frames:

Number of lost frames

Cyclic frames:

Number of cyclic frames

Acyclic frames:

Number of acyclic frames

Memory Usage**Current:**

Current memory usage in bytes

Max:

Maximum memory usage in bytes

6.2.2 Process Data Image

In this tab, the user can see and change the values of the process variables. The variables will be forced to the value the user entered. The user can press release to release the variable. If one or two variables are selected, a chart of the values is shown. Also resize and zoom is possible to see more details. The chart will be updated every 250 milliseconds:

Device Editor

General | Process Data Image | Watch list | Performance | Trace Data | CoE Object-Dictionary | History

Variables Release all Export

Name	Datatype	Offset	Size	Value	Forced
Slave_1010 [EK1101-0080].ID.ID	UINT	IN : 155.0	2.0	1	<input type="checkbox"/>
Slave_1014 [EL3162].Channel 1.Status	BYTE	IN : 157.0	1.0	0	<input type="checkbox"/>
Slave_1014 [EL3162].Channel 1.Value	INT	IN : 158.0	2.0	0	<input type="checkbox"/>
Slave_1014 [EL3162].Channel 2.Status	BYTE	IN : 160.0	1.0	0	<input type="checkbox"/>
Slave_1014 [EL3162].Channel 2.Value	INT	IN : 161.0	2.0	0	<input type="checkbox"/>
Slave_1015 [EL1008].Channel 1.Input	BOOL	IN : 163.0	0.1	0	<input type="checkbox"/>
Slave_1015 [EL1008].Channel 2.Input	BOOL	IN : 163.1	0.1	0	<input type="checkbox"/>
Slave_1015 [EL1008].Channel 3.Input	BOOL	IN : 163.2	0.1	0	<input type="checkbox"/>

Add to watch list

Chart

Edit Variable

Value: Force Release

It is also possible to add the variables to a watch list (next chapter).

6.2.3 Watch list

In this tab, the user can monitor selected variables. He can go through the slaves and add variables to the watch list to monitor them. The user can also export or import the watch list, so changes can be saved:

Device Editor

General | Process Data Image | Watch list | Performance | Trace Data | CoE Object-Dictionary | History

Variables Release all Export

Name	Datatype	Offset	Size	Value	Forced
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Status byte	USINT	IN : 13.0	1.0	136	<input type="checkbox"/>
Slave_1014 [EL3162].Channel 1.Value	INT	IN : 158.0	2.0	0	<input type="checkbox"/>
Slave_1013 [EL4132].Channel 2.Output	INT	OUT : 170.0	2.0	0	<input type="checkbox"/>

Save watch list Load watch list Remove from watch list


Chart

Edit Variable


Value: Dec Hex Force Release

6.2.4 Performance

This tab is split into two sub tabs. On one the user can see the busload per cycle and per second:




On the other tab the user can the CPU load. In the grid is a list of all running jobs and how long they take. In the diagram above is a summary of all jobs. When a job is selected, the chart shows how many times a job has taken how long to complete.



6.2.5 Trace Data (Expert)

In this tab, the user can see and change the values of the trace variables. If he selects a variable he will see a chart of the values. The chart will be updated every 250 milliseconds:



The screenshot shows the 'Device Editor' interface with the 'Trace Data' tab selected. The 'Variables' section contains a table with the following data:

Name	Datatype	Offset	Size	Value
Inputs.DevicesState	UINT	IN : 173.0	2.0	8
Inputs.BusTime	UDINT	IN : 179.0	4.0	3904556720

Below the table is a 'Chart' area displaying a line graph for the selected variable 'Inputs.BusTime'. The y-axis ranges from 0 to 5000... The graph shows a green line that starts at a low value, rises to a peak, then drops sharply to zero, and then gradually increases again.

At the bottom, the 'Edit Variable' section shows the current value: 3904556720. There are radio buttons for 'Dec' (selected) and 'Hex', and a 'Write' button.

6.2.6 CoE Object-Dictionary (Expert)

In this tab, the user can see and change the values of the object dictionary of the master:

Device Editor

General | Process Data Image | Watch list | Performance | Trace Data | **CoE Object-Dictionary** | History

Description from Master Single Object

Values

Index	Name	Value	Type	Flags
0x1000	Device type	1100 (0x44C)	UDINT	-- -- -- (RO RO RO)
0x1008	Device name	EC-Master	STRING(9)	-- -- -- (RO RO RO)
0x1009	Hardware version	V3.2.0.03	STRING(9)	-- -- -- (RO RO RO)
0x100A	Software version	V3.2.0.03	STRING(9)	-- -- -- (RO RO RO)
▶ 0x1018	Identity	4 (0x04)	USINT	-- -- -- (RO RO RO)
▶ 0x10F3	History	18 (0x12)	USINT	-- -- -- (RO RO RO)
0x2000	Master State Change Command	0 (0x00)	UDINT	-- -- -- (RW RW RW)
0x2001	Master State Summary	79745 (0x13781)	UDINT	-- -- -- (RO RO RO)
▶ 0x2002	Bus Diagnosis Object	14 (0x0E)	USINT	-- -- -- (RO RO RO)
▶ 0x2003	Redundancy Diagnosis Object	4 (0x04)	USINT	-- -- -- (RO RO RO)
▶ 0x2004	Notification Counter Object	15 (0x0F)	USINT	-- -- -- (RO RO RO)
▶ 0x2005	MAC Address Object	4 (0x04)	USINT	-- -- -- (RO RO RO)
▶ 0x2006	Mailbox Statistics Object	65 (0x41)	USINT	-- -- -- (RO RO RO)
▶ 0x2007	Add History Diagnosis Message Command	5 (0x05)	USINT	-- -- -- (WO WO WO)
0x2010	Debug Register	5 (0x05)	ULINT	-- -- -- (RW RW RW)

Edit Value

Value: Dec Hex Write

Lists of CoE Object-Dictionary entries

- Entries are uploaded by the master from the slave
- **The “Flags” column tells the user if this entry is an PDO entry and if it can be edited**
 - “AA BB (CC DD EE)”
 - AA = Mapping as RX PDO or not
 - BB = Mapping as TX PDO or not
 - CC = Access rights for PreOp (RO, WO, RW)
 - DD = Access rights for SafeOp (RO, WO, RW)
 - EE = Access rights for Op (RO, WO, RW)


Buttons

Update:

Changes the selected entry

6.2.7 Master History (Expert)

In this tab, the user can see and change the diagnosis history of the master (Supported from EC-Master V2.7 and above). It is also possible to export the data:



Device Editor

General | Process Data Image | Watch list | Performance | Trace Data | CoE Object-Dictionary | **History**

Settings

Show Info Messages: True
 Show Warning Messages: True
 Show Error Messages: True
 Show Emergency Messages: False
 Current Mode: Overwrite Mode

Messages Export

Severity	Time	ID	Acknowledged	Code	Message
ERR	11.05.2023 09:55:41	022	No	0x0001000A (0x0219)	Unexpected response on cyclic Ethernet frame
ERR	11.05.2023 09:55:41	021	No	0x0001000A (0x0219)	No response on cyclic Ethernet frame
ERR	11.05.2023 09:55:39	020	No	0x0001000A (0x0219)	Unexpected response on cyclic Ethernet frame
ERR	11.05.2023 09:55:39	019	No	0x0001000A (0x0219)	No response on cyclic Ethernet frame
ERR	11.05.2023 09:53:08	018	No	0x0001000A (0x0219)	Unexpected response on cyclic Ethernet frame
ERR	11.05.2023 09:53:08	017	No	0x0001000A (0x0219)	No response on cyclic Ethernet frame
ERR	11.05.2023 09:52:17	016	No	0x0001000A (0x0219)	Unexpected response on cyclic Ethernet frame
ERR	11.05.2023 09:52:17	015	No	0x0001000A (0x0219)	No response on cyclic Ethernet frame
ERR	11.05.2023 09:52:16	014	No	0x0001000A (0x0219)	Unexpected response on cyclic Ethernet frame

Number of messages: 17 / 200

Change Message Handling

Tasks: Execute

Settings

Show Info Messages:

Info messages will be collected from master

Show Warning Messages:

Warning messages will be collected from master

Show Error Messages:

Error messages will be collected from master

Show Emergency Messages:

Not supported from master

Current Mode:

Overwrite Mode: Messages will be overwritten if buffer is full Acknowledge Mode: Not supported from master

Messages

List of history messages

Change Message Handling

Enable/Disable Info Messages:

Enable or disable info messages


- Enable/Disable Warning Messages:**
Enable or disable warning messages
- Enable/Disable Info Messages:**
Enable or disable info messages
- Enable/Disable Error Messages:**
Enable or disable error messages
- Enable Acknowledge Mode:**
Enable acknowledge mode
- Clear All Messages:**
Clear all messages

6.3 Slave

This section shows the current “health” state of the selected slave and helps the user to analyze slave related problems.

6.3.1 General (Slave)

In this tab, the user can see and change the current state of the state machine of the slave. He can see and clear also the current error state of the slave:



State Machine

Current State:
Current state of the selected slave

Requested State:

Requested state of the selected slave

Change State:

Slave can reach the states INIT, BOOTSTRAP, PRE-OP, SAFE-OP and OP.

Note: The BOOTSTRAP mode can only be reached from the INIT state.

Software Diagnostics**State Machine Error:**

Slave error which occurred during state transition

Hardware Diagnostics**Summary:**

Summary of hardware diagnostics

Port A:

Port specific error

Port D:

Port specific error

Port B:

Port specific error

Port C:

Port specific error

Buttons**Acknowledge:**

Acknowledge the current error state and notify the user again if error state was changed again.

Possible warning and errors:**Disturbed Connection:**

There may be problems in the connection between two slaves. The message will tell either that there is a problem between two slaves or two ports. The warning appears if error counters are increased (Invalid Frame: 0x300-0x306, RX Errors: 0x301-0x307, Lost Link: 0x308-0x30B). The value from which a warning is issued can be set in the User.xml files in C:\ProgramData\EC-Engineer. More information below.

Bad Connection:

The same as "Disturbed Connection" but the error counters are higher. The value from which an error is issued can be set in the User.xml files in C:\ProgramData\EC-Engineer. More information below.

Line break:

A line break is detected before a slave. This error is detected by looking at the topology.

Link missing:

A link is missing on input port of the slave. This error is detected by looking at the topology.

Multiple warnings:

There are multiple warning for this port.

Multiple errors:

There are multiple errors for this port.

Multiple warnings and errors:

There are multiple warning and errors for this port.

State Machine:

See ETG1020 “Description of AL Status Codes” or ETG.1000.6. This error is detected by looking at the AL Status (0x130).

How to solve errors?

- Lost Link errors are often caused by the power supply system
- Helpful might be the usage of an extra power supply
- It is recommended to clear all error counters after startup

How to change amount of errors leading to a warning or error:

- Open C:\ProgramData\EC-Engineer
- Search for DiagGeneral
- **Change the values which should be adjusted**
 - LostLink: The value entered is used
 - All others are calculated depending on the amount of cyclic frames: $(\text{Value} / \text{CyclicFrames}) \times 10^6$

Note: Please refer also the “ETG.1600 EtherCAT Installation Guideline”: <http://www.ethercat.org/ETG1600>.

6.3.2 Variables

In this tab, the user can see and change the values of the process variables. The variables will be forced to the value the user entered. The user can press release to release the variable. If one or two variables are selected, a chart of the values is shown. Also resize and zoom is possible to see more details. The chart will be updated every 250 milliseconds:

Device Editor

General Variables ESC Register EEPROM Extended Diagnosis DC Diagnosis CoE Object-Dictionary FoE

Variables

Name	Datatype	Offset	Size	Value	Forced
Slave_1019 [VIPA 053-1EC00].Inputs.Hardware Interrupt Counter	UDINT	IN : 4.0	4.0	0	<input type="checkbox"/>
Slave_1019 [VIPA 053-1EC00].Inputs.Diagnostic Interrupt Counter	UDINT	IN : 8.0	4.0	0	<input type="checkbox"/>
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 0	BOOL	IN : 12.0	0.1	0	<input type="checkbox"/>
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 1	BOOL	IN : 12.1	0.1	0	<input type="checkbox"/>
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 2	BOOL	IN : 12.2	0.1	0	<input type="checkbox"/>
Slave_1019 [VIPA 053-1EC00].Module 2 (021-1BD00).Inputs.DI 3	BOOL	IN : 12.3	0.1	0	<input type="checkbox"/>
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Status byte	USINT	IN : 13.0	1.0	136	<input type="checkbox"/>
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 1	USINT	IN : 14.0	1.0	0	<input type="checkbox"/>
Slave_1019 [VIPA 053-1EC00].Module 4 (040-1BA00).Inputs.Input byte 2	USINT	IN : 15.0	1.0	0	<input type="checkbox"/>

Add to watch list

Chart

Edit Variable

Value: Dec Hex Force Release

6.3.3 ESC Register (Expert)

In this tab, the user can see and change the values of the registers. In the settings section he can set the offset and the length. If he activates the compact view, he will only see the registers which have a description:

Device Editor

General | Variables | ESC Register | EEPROM | Extended Diagnosis | DC Diagnosis

Settings

Offset: 0x0000 [Dec] [Hex]

Length: 0x0400 [Dec] [Hex]

Compact:

Registers

Index	Name	Value	Type
▶ 0x0000	Type	18 (0x12)	USINT
▶ 0x0001	Revision	0 (0x00)	USINT
▶ 0x0002	Build	3 (0x0003)	UINT
▶ 0x0004	FMMUs supported	3 (0x03)	USINT
▶ 0x0005	SyncManagers supported	4 (0x04)	USINT
▶ 0x0006	RAM Size	1 (0x01)	USINT
▶ 0x0007	Port Descriptor	74 (0x4A)	USINT
▶ 0x0008	ESC Features supported	252 (0x00FC)	UINT
▶ 0x0010	Configured Station Address	1011 (0x03F3)	UINT
▶ 0x0012	Configured Station Alias	0 (0x0000)	UINT
▶ 0x0020	Write Register Enable	0 (0x00)	USINT
▶ 0x0021	Write Register Protection	0 (0x00)	USINT
▶ 0x0030	ESC Write Enable	0 (0x00)	USINT

Edit Register

Value: 0 [Type] [Hex] Write

6.3.4 EEPROM (Expert)

This tab consists of 2 views:

Smart View

In this view, the user can see and change the values of the EEPROM.

Device Editor

General | Variables | ESC Register | **EEPROM** | Extended Diagnosis | DC Diagnosis

Smart View Hex View

EEPROM Values

Index	Name	Value	Type
0x0000	PDI Control	260 (0x0104)	UINT
0x0001	PDI Configuration	128 (0x0080)	UINT
0x0002	Pulse Length of SYNC Signals	1000 (0x03E8)	UINT
0x0003	Extended PDI Configuration	65535 (0xFFFF)	UINT
0x0004	Configured Station Alias	0 (0x0000)	UINT
0x0005	Reserved	0 (0x00000000)	UDINT
0x0007	Checksum	199 (0x00C7)	UINT
0x0008	Vendor ID	2 (0x00000002)	UDINT
0x000A	Product Code	147599442 (0x08CC3052)	UDINT
0x000C	Revision Number	1245184 (0x00130000)	UDINT
0x000E	Serial Number	0 (0x00000000)	UDINT
0x0010	Execution Delay	0 (0x0000)	UINT
0x0011	Port0 Delay	0 (0x0000)	UINT
0x0012	Port1 Delay	0 (0x0000)	UINT
0x0013	Reserved	0 (0x0000)	UINT
0x0014	Bootstrap Receive Mailbox Offset	0 (0x0000)	UINT

Edit EEPROM Value

Value: Dec Hex Write

Hex View

In this view, the user can create an EEPROM from an ESI file, upload the EEPROM from the slave, load an EEPROM from the disk, download the EEPROM to the slave or save the EEPROM to disk.

Device Editor

General | Variables | ESC Register | **EEPROM** | Extended Diagnosis | DC Diagnosis

Smart View Hex View

EEPROM

```

0000: 04 01 80 00 E8 03 FF FF 00 00 00 00 00 00 C7 00 .....
0010: 02 00 00 00 52 30 CC 08 00 00 13 00 00 00 00 00 ...R0..
0020: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0030: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0040: 00 00 06 00 8D 0E 00 00 00 00 00 00 00 00 00 .....
0050: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0060: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0070: 00 00 00 00 00 00 00 00 00 00 00 00 0F 00 01 00 .....
0080: 0A 00 6F 00 10 06 45 4C 32 32 35 32 06 44 69 67 ..o...EL 2252.Dig
0090: 4F 75 74 20 44 69 67 69 74 61 6C 65 20 41 75 73 Out.Digi tale.Aus
00A0: 67 61 6E 67 6B 6C 65 6D 6D 65 6E 20 28 45 4C 32 gangklem men.(EL2
00B0: 78 78 78 29 30 45 4C 32 32 35 32 20 32 4B 2E 20 xxx)0EL2 252.2K..
00C0: 44 69 67 2E 20 41 75 73 67 61 6E 67 20 32 34 56 Dig..Aus gang.24V
00D0: 2C 20 30 2E 35 41 2C 20 44 43 20 54 69 6D 65 20 ,.0.5A,. DC.Time.
00E0: 53 74 61 6D 70 0B 44 63 54 69 6D 65 53 74 61 6D Stamp.Dc TimeStam
00F0: 70 07 53 79 73 54 69 6D 65 08 46 65 65 64 62 61 p.SysTim e.Feedba
0100: 63 6B 10 44 43 20 53 79 6E 63 20 41 63 74 69 76 ck.DC.Sy nc.Activ
0110: 61 74 65 08 41 63 74 69 76 61 74 65 0D 44 43 20 ate.Acti vate.DC.
0120: 53 79 6E 63 20 53 74 61 72 74 09 53 74 61 72 74 Sync.Sta rt.Start
0130: 54 69 6D 65 09 43 68 61 6E 6E 65 6C 20 31 06 4F Time.Cha nnel.1.O
0140: 75 74 70 75 74 08 54 72 69 53 74 61 74 65 09 43 utput.Tr iState.C
0150: 68 61 6E 6E 65 6C 20 32 08 52 65 73 65 72 76 65 hannel.2 .Reserve
0160: 64 FF 1F 00 10 00 02 00 01 04 0C 00 00 00 00 00 d.....
    
```

EEPROM Operations


Timeout (ms) Dec Hex

Data Size (byte) Dec Hex

Create from ESI Upload from Slave Load from File
Download to Slave Save to File

6.3.5 Extended Diagnosis (Expert)

In this tab, the user can see the extended diagnosis information:



Common Error Counter

Processing Error Counter:

Indicates that slave received “not EtherCAT frames”, which are not allowed in the EtherCAT segment (of course acceptable in a test environment)

PDI Error Counter:

Counts if a PDI access has an interface error (read from register: 0x30D)


Port 0..3

- Invalid Frame Counter of Port y (read from register: 0x0300+y*2)
- RX Error Counter of Port y (read from register: 0x0300+y*2+8Bit)
- Lost Link Counter of Port y (read from register: 0x0310+y)
- Forwarded RX Error Counter of Port y (read from register: 0x0308+y)

Note: All error counters can be cleared by clicking on *Clear Error Counters* of the context menu of the master.

6.3.6 DC Diagnosis (Expert)

In this tab, the user can see all DC related values of the slave:



The screenshot shows the 'Device Editor' interface with the 'DC Diagnosis' tab selected. Under the 'Distributed Clocks' section, there are four input fields: 'Sync Pulse Active' (set to 'Yes'), 'DC Sync 0 Period' (set to '2000000' with a '[µs]' unit), 'DC Sync 1 Period' (set to '0' with a '[µs]' unit), and 'System Time Difference' (set to '0' with a '[ns]' unit). Below these fields is a note: 'Please activate 'Sync Window Monitoring' option!'.

Distributed Clock

Sync Pulse Active:

Sync pulse was received or not

DC Sync 0 Period:

Configured period for sync unit 0

DC Sync 1 Period:

Configured period for sync unit 1

System Time Difference:

Time difference of slave clock to reference clock


Note: The option “Sync Window Monitoring” must be enabled (see *Distributed Clocks (Expert)*).

6.3.7 CoE Object-Dictionary

This tab consists of 3 modes (in user mode, only the description from ESI or slave is available):

Description from ESI

In this tab, the user can see the description of the object dictionary from ESI and the values from the slave. He can also change the values.



The screenshot shows the 'Device Editor' interface with the 'CoE Object-Dictionary' tab selected. The 'Description from ESI' mode is active. Below the tabs, there are three radio buttons: 'Description from ESI' (selected), 'Description from Slave', and 'Single Object'. A 'Filter Setting Flag' is also present. The main area contains a table with the following data:

Index	Name	Value	Type	Flags
0x1000	Device Type	5001 (0x1389)	UDINT	--- -- (RO RO RO)
0x1008	Device Name	VIPA 053-1EC00	STRING(17)	--- -- (RO RO RO)
0x1009	Hardware Version	03	STRING(3)	--- -- (RO RO RO)
0x100A	Software Version	1.30	STRING(12)	--- -- (RO RO RO)
0x100B	System Version	3 (0x03)	USINT	--- -- (RO RO RO)
▶ 0x1018	Identity	4 (0x04)	USINT	--- -- (RO RO RO)
▶ 0x1600	RxPDO Map	5 (0x05)	USINT	--- -- (RO RO RO)
▶ 0x1602	RxPDO Map	5 (0x05)	USINT	--- -- (RO RO RO)
▶ 0x1603	RxPDO Map	60 (0x3C)	USINT	--- -- (RW RW RW)
▶ 0x1604	RxPDO Map	2 (0x02)	USINT	--- -- (RO RO RO)
▶ 0x1606	RxPDO Map	45 (0x2D)	USINT	--- -- (RW RW RW)
▶ 0x1607	RxPDO Map	5 (0x05)	USINT	--- -- (RO RO RO)
▶ 0x1A01	TxPDO Map	5 (0x05)	USINT	--- -- (RO RO RO)
▶ 0x1A03	TxPDO Map	60 (0x3C)	USINT	--- -- (RW RW RW)
▶ 0x1A05	TxPDO Map	5 (0x05)	USINT	--- -- (RO RO RO)

Below the table is an 'Edit Value' section with a text input field containing '5001', radio buttons for 'Dec' (selected) and 'Hex', and a 'Write' button.

Lists of CoE Object-Dictionary entries

- Entries comes from ESI
- The “Flags” column tells the user if this entry is an PDO entry and if it can be edited
 - “AA BB C D (EE FF GG)”
 - AA = Mapping as RX PDO or not
 - BB = Mapping as TX PDO or not
 - C = Backup Flag
 - D = Settings Flag
 - EE = Access rights for PreOp (RO, WO, RW)
 - FF = Access rights for SafeOp (RO, WO, RW)
 - GG = Access rights for Op (RO, WO, RW)


Buttons

Write:

Writes the selected entry

Description from Slave

In this tab, the user can see the description of the object dictionary and the values from slave. He can also change the values and has the possibility to export the object dictionary.



Device Editor

General Variables ESC Register EEPROM Extended Diagnosis DC Diagnosis CoE Object-Dictionary FoE

Description from ESI Description from Slave Single Object

Values

Export OD Filter Setting Flag

Index	Name	Value	Type	Flags
0x1000	Device Type	5001 (0x1389)	UDINT	---- (RO RO RO)
0x1008	Device Name	VIPA 053-1EC00	STRING(30)	---- (RO RO RO)
0x1009	Hardware Version	03	STRING(8)	---- (RO RO RO)
0x100A	Software Version	1.30	STRING(8)	---- (RO RO RO)
0x100B	System Version	3 (0x03)	USINT	---- (RO RO RO)
▶ 0x1018	Identity	4 (0x04)	USINT	---- (RO RO RO)
▶ 0x1600	RxPDO Map	5 (0x05)	USINT	---- (RO RO RO)
▶ 0x1602	RxPDO Map	5 (0x05)	USINT	---- (RO RO RO)
▶ 0x1603	RxPDO Map	60 (0x3C)	USINT	---- (RW RO RO)
▶ 0x1604	RxPDO Map	2 (0x02)	USINT	---- (RO RO RO)
▶ 0x1606	RxPDO Map	45 (0x2D)	USINT	---- (RW RO RO)
▶ 0x1607	RxPDO Map	5 (0x05)	USINT	---- (RO RO RO)
▶ 0x1A01	TxPDO Map	5 (0x05)	USINT	---- (RO RO RO)
▶ 0x1A03	TxPDO Map	60 (0x3C)	USINT	---- (RW RO RO)
▶ 0x1A05	TxPDO Map	5 (0x05)	USINT	---- (RO RO RO)

Edit Value

Value: Dec Hex Write

Lists of CoE Object-Dictionary entries

- Entries are uploaded from the slave (if “SDO Information Service” is supported)
- **The “Flags” column tells the user if this entry is an PDO entry and if it can be edited**
 “AA BB C D (EE FF GG)” - AA = Mapping as RX PDO or not - BB = Mapping as TX PDO or not - C = Backup Flag - D = Settings Flag - EE = Access rights for PreOp (RO, WO, RW) - FF = Access rights for SafeOp (RO, WO, RW) - GG = Access rights for Op (RO, WO, RW)

Buttons

Write:

Writes the selected entry

Single Object

In this tab, the user can read and write the values of the object dictionary of the slave.

Device Editor

General
Variables
ESC Register
EEPROM
Extended Diagnosis
DC Diagnosis
CoE Object-Dictionary
FoE

Description from ESI
Description from Slave
Single Object

Settings

Index	0x1018	Dec Hex
SubIndex	0	Dec Hex
Size	1	Dec Hex
Complete Access	<input type="checkbox"/>	

Operation

	Write
	Read

Settings

Index:

Index of the CoE value

SubIndex:

SubIndex of the CoE value

Size:

Size of the CoE value (only used for reading)

Complete Access:

Activate, if complete access mode should be used for reading or writing the CoE value (can be used only if it is supported from slave)

Operation

Write:

Writes the value to the slave (Hex format, like: "00 11 22 33 ...")

Read:

Reads the value from slave (Hex format, like: "00 11 22 33 ...")

6.3.8 SoE Object-Dictionary

Device Editor

General Variables ESC Register EEPROM Extended Diagnosis **SoE-Object-Dictionary** FoE

Description from ESI Single Object

Values

Index	Name	Value	Channel
S-0-0001	Control unit cycle time (TNcyc)	1000 (0x3E8)	A
S-0-0002	Communication cycle time (tSync)	1000 (0x3E8)	
S-0-0007	Feedback acquisition capture point (t4)	-	
S-0-0011	Class 1 diagnostic (C1D)	-	
S-0-0012	Class 2 diagnostic (C2D)	-	
S-0-0013	Class 3 diagnostic (C3D)	-	
S-0-0015	Telegram type	7 (0x07)	
S-0-0016	Configuration list of AT	(list)	
S-0-0017	IDN-list of all operation data	(list)	
S-0-0018	IDN-list of operation data for CP2	(list)	
S-0-0019	IDN-list of operation data for CP3	(list)	
S-0-0020	IDN-list of operation data for CP4	(list)	
S-0-0021	IDN-list of invalid operation data for CP2	(list)	
S-0-0022	IDN-list of invalid operation data for CP3	(list)	
S-0-0024	Configuration list of MDT	(list)	

Edit Value

Value:

Lists of SoE Object-Dictionary entries

- Values are uploaded by the master from the slave
- Entries comes from the ESI

Buttons

Write:

Writes the selected entry

Expert View

In this tab, the user can read and write the values of the object dictionary of the slave:

Device Editor

General | Variables | ESC Register | EEPROM | Extended Diagnosis | SoE-Object-Dictionary | FoE

Description from ESI Single Object

Settings

Channel	<input type="text" value="0"/>	
IDN	<input type="text" value="0"/>	<input type="button" value="Dec"/> <input type="button" value="Hex"/>
Size	<input type="text" value="2"/>	<input type="button" value="Dec"/> <input type="button" value="Hex"/>

Operation

<input type="text"/>	<input type="button" value="Write"/>
<input type="text"/>	<input type="button" value="Read"/>

Settings

Channel:

Channel of the SoE value

IDN:

Index of the CoE value

Size:

Size of the CoE value (only used for reading)

Operation

Write:

Writes the value to the slave (Hex format, like: "00 11 22 33 ...")

Read:

Reads the value from slave (Hex format, like: "00 11 22 33 ...")

6.3.9 File over Ethernet (FoE)

In this tab, the user has the possibility to download or upload a file to the slave:

Device Editor

General | Variables | ESC Register | EEPROM | Extended Diagnosis | DC Diagnosis | CoE Object-Dictionary | **FoE**

FoE Download

Local Filename

Slave Filename

Password (hex) Dec

Timeout (s) 60

Download to Slave

FoE Upload

Local Filename

Slave Filename

Password (hex) Dec

Timeout (s) 60

Max File Size (kb) 3000

Upload from Slave

FoE Operations

Local Filename:

Name of the file on the harddrive

Slave Filename:

Name of the file on the slave

Password:

Password on the slave as a hex-number

Timeout:


Timeout for downloading or uploading the file in milliseconds

Max File Size:

Maximal file size which should be uploaded from the slave in kilo bytes

6.3.10 Slave History (Expert)

In this tab, the user can see and change the diagnosis history of the slave. It is also possible to export the data:



Device Editor

General | Variables | ESC Register | EEPROM | Extended Diagnosis | DC Diagnosis | CoE Object-Dictionary | **History** | FoE

Settings

Show Info Messages: True
 Show Warning Messages: True
 Show Error Messages: True
 Show Emergency Messages: False
 Current Mode: Overwrite Mode

Messages Export

Severity	Time	ID	Acknowledged	Code	Message
INF	11.05.2023 09:52:14	055	No	0x1B77E000 (0x1100)	Detection of operation mode completed: 0x100, 0
INF	11.05.2023 09:52:14	006	No	0x1B77E000 (0x1135)	Cycle time o.k.: 2652
INF	11.05.2023 08:45:42	053	No	0x1B77E000 (0x1100)	Detection of operation mode completed: 0x100, 0
INF	11.05.2023 08:45:42	054	No	0x1B77E000 (0x1135)	Cycle time o.k.: 2634
INF	11.05.2023 08:45:27	052	No	0x1B77E000 (0x1135)	Cycle time o.k.: 2705
INF	11.05.2023 08:45:26	051	No	0x1B77E000 (0x1100)	Detection of operation mode completed: 0x100, 0
INF	11.05.2023 08:45:09	049	No	0x1B77E000 (0x1100)	Detection of operation mode completed: 0x100, 0
INF	11.05.2023 08:45:09	050	No	0x1B77E000 (0x1135)	Cycle time o.k.: 2614
INF	11.05.2023 08:44:54	047	No	0x1B77E000 (0x1100)	Detection of operation mode completed: 0x100, 0

Number of messages: 50 / 50

Change Message Handling

Tasks: Execute

Settings

Show Info Messages:

Info messages will be collected from slave

Show Warning Messages:

Warning messages will be collected from slave

Show Error Messages:

Error messages will be collected from slave

Show Emergency Messages:

Emergency messages will be collected from slave

Current Mode:

Overwrite Mode: Messages will be overwritten if buffer is full
 Acknowledge Mode: Messages will be discarded if buffer is full

Messages

List of history messages

Change Message Handling

Enable/Disable Info Messages:

Enable or disable info messages

Enable/Disable Warning Messages:

Enable or disable warning messages

Enable/Disable Info Messages:

Enable or disable info messages

Enable/Disable Error Messages:

Enable or disable error messages

Enable/Disable Emergency Messages:

Enable or disable emergency messages

Enable Acknowledge Mode:

Enable acknowledge mode

Enable Overwrite Mode:

Enable overwrite mode

Clear All Messages:

Clear all messages (only available if “Overwrite Mode” is active)

Clear All Acknowledged Messages:


Clear all acknowledged messages (only available if “Acknowledge Mode” is active)

Acknowledge All Messages:

Acknowledge all messages, that they can be overwritten from new messages (only available if “Acknowledge Mode” is active)


6.3.11 Motion (Motion Mode only)

In this tab, the user can see and change the motion settings of the slave. He can read important variables and change velocity and direction of the axis. Also gearing and camming are possible to use:



6.3.12 Simulator (Simulator only)

In this tab, the user can see and change the simulator settings of the slave. He can manipulate the slave e.g. power, disconnect and produce errors:



The screenshot shows the 'Device Editor' window with the 'Simulator' tab selected. The interface includes several sections for controlling the slave:

- State Machine:** A text box labeled 'Current State' containing the value 'Op'.
- Slave Power:** A description 'Change the power condition of the slave. After a power cycle the slave is in INIT.' followed by two buttons: 'Power off' and 'Power on'.
- Slave Connection:** A description 'Change slave connection. Unplug or change connection to previous slave. Does not power off the slave.' followed by a 'Connect to Slave Address' field with a value of '1001' and a 'Port' dropdown menu set to 'B'. Below these are 'Disconnect' and 'Connect' buttons.
- CRC Error:** A description 'Generate a CRC error at a specific port (once or probability).' followed by a 'Port' dropdown menu set to 'A' and a 'Probability (%)' field with a value of '0,01'. Below are 'Set once', 'Set random', and 'Reset random' buttons.
- Link Loss:** A description 'Generate a Link Loss at a specific port for a specific time (once or probability).' followed by a 'Port' dropdown menu set to 'A', a 'Down time (s):' field with a value of '5,0', and a 'Probability (%)' field with a value of '0,01'. Below are 'Set once', 'Set random', and 'Reset all ports' buttons.

State Machine

Shows the current state of the slave

Slave Power

Power off:

Turn the slave power off

Power on:

Turn the slave on to Init state

Slave Connection

Disconnect:

Disconnect the slave. Slave will not be turned off

Connect:

Connect slave to selected address and port. Default is the port where the slave was connected before

CRC Error

Set once:

Create one CRC error at the selected port

Set random:

Generate CRC errors at the selected port with the selected probability until reset is executed

Reset random:

Reset the CRC generation

Link Loss

Set once:

Create one Link Loss at the selected port for the selected time

Set random:

Generate Link Losses at the selected port with the selected probability for the selected time until reset is executed

Reset random:


Reset the Link Loss on all ports

7 Simulator Mode

With the new EC-Engineer it is possible to use the EC-Simulator.

There are two possibilities:

1. The user can use the Simulator EMI file and create an EXI File to start the simulator. It is also possible to connect to a remote system with the running Simulator. More information about offline configuration and remote diagnosis can be found in the Getting Started Chapter.
2. The second possibility is, that the user has already a configuration with a master unit. Now the user can do a right click on the master unit and select: "Add EC-Simulator Unit (linked)". A linked simulator unit is added. The user can change the connection settings of the simulator. Now, it is possible to start the master with the simulator link layer and also connect via RAS with the simulator node.




8 Additional Tools

8.1 ESI-Manager

ESI-Manager can be found through the main menu File -> ESI-Manager.


This dialog helps the user to administrate his ESI and SCI files. Here, he can add/delete/export ESI and SCI files.



8.2 EMI-Manager

EMI-Manager can be found through the main menu File -> EMI-Manager.

This dialog helps the user to administrate his EtherCAT Master Information (EMI) files.



EMI files, are files which are specify the master features. Means that options and dialogs can be restricted to those features which are supported by the control system, e.g. available cycle times, support of scan for MDP modules or DC synchronization.

8.2.1 Administration


This dialog helps the user to administrate his EtherCAT Master Information (EMI) files.

By default EC-Engineer has two files included (read-only):

- EtherCATMaster_ClassA.emi: EMI template which is prepared for configuring a “Class A” master
- EtherCATMaster_ClassB.emi: EMI template which is prepared for configuring a “Class B” master

If the user wants to customize EC-Engineer, he can create a new EMI file with defaults, copy an existing EMI template or import an EMI file.


If he wants to add new properties to a group, he can add this only to the group “Parameters”. This group is by default empty, but if user has added some properties, he will see the list of properties on tab “Advanced Options (Expert)” of the master, where the values can be modified.



8.2.2 Supported Entries

The following EMI entries are supported:

Master Group



Device Editor

Master | Script Automation | Process Data Image | Watch list | EtherCAT P | Trace Data | Advanced Options | Slave to Slave | Distributed Clocks | Tasks + Sync Uni

General

Unit Name: Class-A Master

Cycle Time [us]: 1000

Source MAC address:

Slaves connected to local system

Link Layer: Ndis

Network Adapter: EtherCAT-Test (Intel(R) Ethernet Server Adapter I210-T1)

Select

Slaves connected to remote system

Protocol: RAS

IP Address: 127 . 0 . 0 . 1

Port: 6000

Master-Instance: 0

Select

Slaves simulated (SIL)

Select

Slaves captured

Capture File: ...

Select

Display Group:

Shows or hides group

Lock Group:

Locks or unlocks group

Name of Master-Unit:

Default Master-Unit name

Show name of Master-Unit:

Enable if user should be able to view and change the name of the Master-Unit

Lock name of Master-Unit:

Enable if user should not be able to change the name of the Master-Unit

Cycle Time:

Default Cycle Time

Show Cycle Time:

Enable if user should be able to view and change the Cycle Time

Lock Cycle Time:

Enable if user should not be able to change the Cycle Time

List values of Cycle Time:

Enter possible values of Cycle Time

Frequency:

Default Frequency

Show Frequency:

Enable if user should be able to view and change the Frequency

Lock Frequency:

Enable if user should not be able to change the Frequency

List values of Frequency:

Enter possible values of Frequency

Cycle Time Mode:

Enter Cycle Time Mode (0 = Cycle Time, 1 = Frequency)

Init Command Retries:

Init Command Retries

Maximal Slave Count:

Enter maximal count of slaves which are allowed to configure (0 = use default limit of master)

Slave Start Address:

Enter default start address for all slaves

Scan for MDP slaves:

Enable for activating MDP-Scan if it is supported from slave

PDO Upload:

Enable for activating PDO upload during scan if it is supported from slave

Byte-Align Process Data Image:

Enable if process data image should be byte aligned and not as small as possible

Edit Complete Variable Name:

Enable if user should be able to edit the complete variable name

Process Image Layout:

Enter process image layout features (0 = default, 0x1 = with protocol data, 0x2 = with VLAN tag, 0x4 = without frame alignment, 0x8 = alphabetic port order, 0x10 = Compatibility to ENI spec V1.0.0, 0x20 = Moves AL Status command to the end), 0x40 = Disable command splitting

Output Port Vendor Id:

Enter output port vendor id of the master (0 = All Vendors, 1..n = Specific Vendor)


Word-Aligned EtherCAT Datagrams:

Enable if EtherCAT datagrams should be word aligned

Cyclic Frame Layout:

Enter cyclic frame layout mode (0 = default, 1 = single logical command per frame)

Ethernet Type UDP:



Remove DC NOP Command:

Does not include NOP Command in ENI

Cable Red active:

Sets disable LRW for all slaves to use cable redundancy

Local System

Device Editor

Master | Process Data Image | Watch list | Trace Data | Advanced Options | Slave to Slave | Distributed Clocks | Tasks + Sync Units | Data Acquisition

General

Unit Name:

Cycle Time [us]:

Source MAC address:

Slaves connected to local system

Link Layer:

Network Adapter: Select

Slaves connected to remote system

Protocol:

IP Address:

Port:

Master-Instance: Select

Slaves simulated (SiL) Select

Slaves captured

Capture File: ... Select

Display Group:

Shows or hides group

Lock Group:

Locks or unlocks group

Network Adapter:

Enter index of Network Adapter in the Network Adapter List

Show Network Adapter:

Enable if user should be able to view and change the Network Adapter

Lock Network Adapter:

Enable if user should not be able to change the Network Adapter

DCM on:

EC-Engineer deactivated DCM on default. Enable if it should be turned off

Remote System

Device Editor

Master | Process Data Image | Watch list | Trace Data | Advanced Options | Slave to Slave | Distributed Clocks | Tasks + Sync Units | Data Acquisition

General

Unit Name:

Cycle Time [us]:

Source MAC address:

Slaves connected to local system

Link Layer:

Network Adapter:

Select

Slaves connected to remote system

Protocol:

IP Address:

Port:

Master-Instance:

Select

Slaves simulated (SIL)

Select

Slaves captured

Capture File:

Select

Display Group:

Shows or hides group

Lock Group:

Locks or unlocks group

Protocol:

Select protocol for Remote System

Show Protocol:

Enable if user should be able to view and change the protocol

Lock Protocol:

Enable if user should be not able to change the protocol

IP Address:

Enter IP Address for Remote System

Show IP Address:

Enable if user should be able to view and change the IP Address

Lock IP Address:

Enable if user should be not able to change the IP Address

Port:

Enter Port for Remote System

Show Port:

Enable if user should be able to view and change the Port"

Lock Port:

Enable if user should be not able to change the Port

Master-Instance:


Enter Master-Instance number

Show Master-Instance:

Enable if user should be able to view and change the Master-Instance

Lock Master-Instance:

Enable if user should be not able to change the Master-Instance

Offline Diagnosis


The screenshot shows the 'Device Editor' window with the following configuration options:

- Master** (selected tab): Process Data Image, Watch list, Trace Data, Advanced Options, Slave to Slave, Distributed Clocks, Tasks + Sync Units, Data Acquisition, Motion.
- General**
 - Unit Name: Class-A Master
 - Cycle Time [us]: 1000
 - Source MAC address: A0-36-9F-30-00-3B
- Slaves connected to local system**
 - Link Layer: Ndis
 - Network Adapter: EtherCAT-Test (Intel(R) Ethernet Server Adapter I210-T1)
 - Deselect button
- Slaves connected to remote system**
 - Protocol: RAS
 - IP Address: 127 . 0 . 0 . 1
 - Port: 6000
 - Master-Instance: 0
 - Select button
- Slaves simulated (SiL)**
 - Select button
- Slaves captured** (highlighted with a red border)
 - Capture File: [Empty field]
 - Select button

Display Group:

Shows or hides group

Lock Group:

Locks or unlocks group

Simulator Functions**Display Group:**

Shows or hides group

Lock Group:

Locks or unlocks group

Distributed Clocks

Device Editor

Master
Process Data Image
Watch list
Trace Data
Advanced Options
Slave to Slave
Distributed Clocks
Tasks + Sync Units
Data Acquisition

Reference Clock

Name Auto select

Clock Adjustment

Master Shift (Master clock follows reference clock) or

Master Reference Clock (System time provided by master device) or

Link Layer Reference Clock (System time provided by network device) or

Off

Bus Shift (Reference clock follows master clock)

DCX (Master and reference clock follow external clock)

Options

Sync Window Monitoring

Show 64Bit System Time

Slaves with active DC

Slave_1011 [EL2252] (1011)
 Slave_1022 [EL2202-0100] (1022)
 Slave_1023 [EL2202-0100] (1023)
 Slave_1026 [EL7201] (1026)

Display Group:

Shows or hides group

Clock Adjustment:

Enter clock adjustment value (0 = default, 1 = Master Shift, 2 = Bus Shift)

Lock Clock Adjustment:

Enable if user should not be able to change clock adjustment

Show Clock Adjustment:

Enable if clock adjustment should be visible

Continuous Propagation Compensation:

Enter default value of Continuous Propagation Compensation

Show Continuous Propagation Compensation:

Enable if user should be able to change value of Continuous Propagation Compensation

Sync Window Monitoring:

Enter default value of Sync Window Monitoring

Show External Mode:

Enable if user should be able to use an external sync device as reference clock

System Time 64 Bit:

Enter default value of System Time 64 Bit

Features**AoE:**

Enable if master supports AoE

EoE:

Enable if master supports EoE

FoE:

Enable if master supports FoE

SoE:

Enable if master supports SoE

VoE:

Enable if master supports VoE

Export Variables:

Enable if user should be able to export variables

Show Enable Column:

Shows column for enable variables on XML export

Generate Slave Name with Type:

Enable if type of slave should be added to slave names on generating ENI file

Lock Variables:

Locks or unlocks variables for editing in diagnosis mode

Show Variable Chart:

Enable if user should be able to view the chart of a variable

Show Variable Comments:

Enable if user should be able to view and edit the comments of a variable

Allow E-Bus as HC Head:

Enable if Ebus shall be allowed as HC Head

ENI Deployment:

yes: something is done with ENI after export, no: nothing done ask: you will be ask to deploy

Deployment Mode:

0: copy to path, 1: execute batch at path

Deployment Path:

Path to copy ENI or to batch for execution

Hot Connect:

Enable if master supports hot connect

Scripts**Display Group:**

Shows or hides the Scripts Tab

P1:**Scan Start Script 1:**

First script executed before scanning

Scan Start Script 2:

Second script executed before scanning

Scan Stop Script 3:

First script executed after scanning

Scan Stop Script 4:

Second script executed after scanning

P2:**Diag Start Script 1:**

First script executed before switch to diag

Diag Start Script 2:

Second script executed before switch to diag


Diag Stop Script 3:

First script executed before switching to config

Diag Stop Script 4:

Second script executed before switching to config

Parameters



User defined properties, which will be written into ENI file and can be interpreted by the application inside EC-Master.

8.3 Network Mismatch Analyzer

If you have a network mismatch in your EtherCAT network it is not so easy to find the problem. For this you have the Network Mismatch Analyzer. You find it in the network main menu. If you see here some “red” entries, means that this is the start point of your network mismatch:

Network Mismatch Analyzer

List of slaves


Please, compare the configured slaves with the connected slaves. If something is red, you have a network configuration mismatch!

Slave Name	Config Type	Config Revision	Config Ident.	Network Type	Network Revision	Network Ident.
Slave_1016 [EL10]	EL1094 [1016]	0x00100000	0	EL1094 [1016]	0x00100000	0
Slave_1017 [EK11]	EK1110 [1017]	0x00100000	0	EK1110 [1017]	0x00100000	0
Slave_1018 [BK11]	BK1120 [1018]	0x00120000	0	BK1120 [1018]	0x00120000	1019
Slave_1019 [VIPA]	VIPA 053-1EC00 [1019]	0x00000012	0	EK1122 [1020]	0x00120000	0
Slave_1020 [EK11]	EK1122 [1020]	0x00120000	0	EK1100 [1021]	0x00120000	2001
Slave_1021 [EK11]	EK1100 [1021]	0x00120000	0	EL2202-0100 [1022]	0x00100064	0
Slave_1022 [EL22]	EL2202-0100 [1022]	0x00100064	0	EL2202-0100 [1023]	0x00100064	0
Slave_1023 [EL22]	EL2202-0100 [1023]	0x00100064	0	EL1114 [1024]	0x00110000	0
Slave_1024 [EL11]	EL1114 [1024]	0x00110000	0	EL7031 [1025]	0x00170000	0
Slave_1025 [EL70]	EL7031 [1025]	0x00170000	0	EL7201 [1026]	0x00130000	0
Slave_1026 [EL72]	EL7201 [1026]	0x00130000	0			

Close

8.4 Line Crossed Analyzer

If you have connected a line to a wrong port, you can see in the Line Crossed Analyzer which slave is incorrectly connected. The wrong entries will be red:




List of slaves
In the list you can see all connected slaves. The red ones are incorrectly connected

AutoInc Address	Station Address	Type
65521	16	EL1094
65520	17	EK1110
65519	18	BK1120
65518	19	VIPA 053-1EC00
65517	20	EK1122
65516	21	EK1100
65515	22	EL2202-0100
65514	23	EL2202-0100
65513	24	EL1114
65512	25	EL7031
65511	26	EL7201

Close

8.5 Inspection Report

If you want to print or show a report about the actual session, it is possible with the inspection report. It shows a lot of different data about the network communication. It is also possible to print a PDF.



Inspection Report

Network Status

Please, select the statistic of which you want to see the details. The complete network status can be also printed.

General

Category	Name	Value
Information	Master Version	3.2.0.3
Information	Cycle Time	2000
Information	Number of found slaves	26
Information	Number of slaves in configuration	26
Information	Number of DC slaves	4
Information	DC in-sync	Yes
Information	Topology Ok	Yes
Information	Link Connected	Yes
Information	Slaves in Master State	Yes
Frame Counter	Sent frames	22305


Print Close

8.6 EoE Endpoint Configuration

If you want to use EoE slaves with your local master, you can activate the EoE Endpoint.

Note: This feature is only available if the package “Tap-Windows” from OpenVPN is installed: <http://openvpn.net/index.php/download/community-downloads.html>

If this package is installed, you will see the following dialog:



Settings

Use EoE Endpoint:

Activate EoE Endpoint support for the selected device


Network Adapter:

List of installed network adapters (TAP)

IP Address:

IP Address of the selected network adapter

8.7 Edit Topology



Disconnect:

Disconnects the selected port

Connect:

Connects the selected slave in the not connect slaves list, with the selected port in the configuration

Up: Moves the slave up in the configuration

Down:

Moves the slave down in the configuration

Scan:

Scans the network. The network is shown by the scanned configuration. It is possible to add slave to the configuration with “Add Slave”.

Apply:


The configuration will be applied to the EC-Engineer (only possible if all slaves are connected)

8.8 Capture File

A capture file could be helpful, if you have a very large system or system is not always available. In that case you can connect to your system, save one or more snapshots into a capture file and analyse the created capture file later.

Another use case is, that your system from time to time some problems. In that case you can activate the automatic mode and create the snapshots every specific interval or based on specific master notifications.

At the moment there are the following options:



Filename

Folder:

Path, where the capture files should be saved

Base file name:

Base file name of the generated capture file name

Date:

Activate, to add the date to the generated capture file name

Time:

Activate, to add the time to the generated capture file name

IP Address:

Activate, to add the IP address to the generated capture file name

Preview:

Shows a preview of the generated capture file name

Content**Process data:**

Activate to add process data to the capture file (read-only)

EEPROM size:

Enter size of the EEPROM (0x86 = default, 0 = no EEPROM)

ESC Register size:

Enter size of the ESC Registers (0x400 = default, 0 = no ESC register)

CoE OD of slaves:

Select the slaves of which the CoE OD information will be captured

None:

CoE OD will be not captured

All:

CoE OD will be captured of all slaves

User defined:

CoE OD will be captured of the defined slaves by physical address (e.g. 1001-1003; 1005)

CoE OD objects:

Enter index of specific objects or all objects will be collected (e.g. 0x1018; 0x7000-0x7FFF)

SDO Info Service:

Activate to use the SDO Info Service for loading the CoE Object Dictionary instead of reading the information from the ESI file.

Automatic Mode**Interval (min):**

Time to wait until next snapshot will be taken

Maximum Snapshots:

Enter count of maximum snapshots

Notifications:

Select the notifications, which will trigger a snapshot. The following notifications are available (for more information about notifications please refer the manual of EC-Master):


- STATECHANGED
- ETH_LINK_CONNECTED
- ETH_LINK_NOT_CONNECTED

- SLAVE_STATECHANGED
- SLAVE_PRESENCE
- SLAVE_INITCMD_RESPONSE_ERROR
- STATUS_SLAVE_ERROR
- SLAVE_UNEXPECTED_STATE
- DC_SLV_SYNC
- DCM_SYNC

8.9 Project Templates

If you have a lot of slaves with the same configuration (e.g. PDOs, InitCmds) you can use a project template. In that case new slaves will be first copied from this template (if available) and then taken from the EST cache. This behaviour is also used for the bus scan.

At the moment there are the following options:



Path: Path to the selected project template

Settings


Activate:

True, for activating this project template (necessary if you want to turn it temporary off)


Ignore Revision:

The revision will be not used as search criteriom

If the project template mode is active, it will be displayed in the status bar:



Normally the first match will be taken from project template. If this is wrong, you can open the context menu *Select from Project Template* and select another one:



8.10 Real-time Support

Normally on Windows you do not have real-time support, but to get DCM in sync you can install the “ECAT driver” in the following modes:

Network driver

The network driver can be used from the optimized link layers

The real-time support is normally hidden in EC-Engineer. It can be activate by copying the specific link layer libraries into the installation directory of EC-Engineer.

For the local system, EC-Engineer will turn on DCM and use the real-time clock for generating the job task cycles. For more information about how to install the “ECAT driver” please refer the manual of *EC-Master Class A DCM* on Windows

8.10.1 Optimized Link Layers

After activating the real-time support the optimized link layer can be selected in the option “Link Layer”:

Device Editor

Master | Process Data Image | Watch list | Trace Data | Advanced Options | Slave to Slave | Distributed Clocks | Tasks + Sync Units | Data Acquisition

General

Unit Name: Class-A Master

Cycle Time [us]: 1000

Source MAC address: A0-36-9F-30-00-3B

Slaves connected to local system

Link Layer: i8254x

Instance: 1

Select

Slaves connected to remote system

Protocol: RAS

IP Address: 127 . 0 . 0 . 1

Port: 6000

Master-Instance: 0

Select

Slaves simulated (SiL)

Select

Slaves captured

Capture File: ...

Select

Depending on the link layer type the user can chose the network adapter or the instance.


The following optimized link layers are currently supported:

- eml1i8254x.dll (Intel PRO/1000 Network Adapters)
- eml1i8255x.dll (Intel PRO/100 Network Adapters)
- eml1IRTL8139.dll (Realtek 8139 Fast Ethernet Adapters)
- eml1IRTL8169.dll (Realtek Gigabit Ethernet Adapters)
- eml1ICCAT.dll (BECKHOFF CCAT)

For more information about optimized link layers and how to install the ECAT driver please refer the manual of [EC-Master Class B EcatDrv for Optimized Link Layers](#)

8.11 Export ENI Variants

With this function it is possible to export different ENI file variants of an config. Therefore a xml file has to be created. Then it is possible to select this xml file and create more ENI files at once. The xml file should look like this:



```

version="1.0" encoding="utf-8"

http://www.w3.org/2001/XMLSchema-instance
http://www.w3.org/2001/XMLSchema

true
D:\temp\enis
true

Config1
1000

Slave1

Config2
4000

```

RenumberBus: If this is true, all slaves will be enumerated in a row. Otherwise each slave stays with his address.

Export Path: The path where the ENI / ECC files should be saved.#

ExportEcc: If true, also the ECC file be exported and not only the ENI.

Each Config needs a name. This name is used for the ENI file and the optional ECC file.

CycleTime (optional): If this is set the cycle time will be changed to this value.

To find a slave in the config the name is required. With that it is possible to remove some slaves from a big config for example.

9 Command Line Interface

For helping users in some special situations and to do not confuse other users the EC-Engineer supports a small command line interface:

/HELP, /?

Shows the help dialog

/CFG = config.ecc

Open a specific configuration file `config.ecc` directly after starting EC-Engineer

/EMI = emi.xml

Sets the path to the EMI file which should be used (Mandatory if ecc does not already exist)

/REMOTE = "127.0.0.1:6000:0"

Activates the remote system, where IP address is "127.0.0.1", port is 6000, master instance is set to 0

/ENIEXPORT = config.eni

Activates an automatic ENI export on close

/EXIEXPORT = config.exi

Activates an automatic EXI export on close

/CYCLETIME = "2000"

Changes the cycle time from ecc or EMI in config

/DIAG

Activates diagnosis mode

/CAPTURE= capture.ecd

Open a specific capture file `capture.ecd` directly after starting EC-Engineer and activates the diagnosis mode

/ENIBUILDER

Activates the EniBuilder support, means two additional context menu entries of the device will be available to export and import the configuration file for the EniBuilder

/PROJECTTEMPLATEPATH

Opens a specific configuration file as project template

/FORCECFG= config.ecc

Activates the "integration" mode, to be able create an ENI file automatically on closing EC-Engineer

Some menu entires are also hidden, like

- "New/Open/Save"
- "EMI Manager"
- "Export Process Variables / Import ENI file / Export ENI file"
- Toolbar

Further supported parameters:

/EMI = emi.xml

Sets the path to the EMI file which should be used (Mandatory)

/LOCAL = "127.0.0.1"

Activates the local system and the network adapter with IP address "127.0.0.1" will be chosen. If you use the optimized LinkLayer you can write `/LOCAL="I8254x"` or `/LOCAL="RTL8169"` (`/LOCAL` or `/REMOTE` or `/CAPTURE` is mandatory).

/REMOTE = "127.0.0.1:6000:0:0"

Activates the remote system, where IP address is "127.0.0.1", port is 6000, master instance is set to 0 and protocol is 0 (RAS). It is also supported to use the DNS name instead of the IP address (*/LOCAL* or */REMOTE* or */CAPTURE* is mandatory). It is also possible to set the parameter for more master instances (only if ecc exists with more master units). Therefore just add the additional parameter with a ';. E.g.: */REMOTE* ="127.0.0.1:6000:1;127.0.0.2:6001:2" or */REMOTE* ="127.0.0.1:6000:1:0;127.0.0.2:6001:2:0"

/CAPTURE = C:/myfile.ccd:0

Activates the offline diagnosis system, where the path to the capture file is c:/myfile.ccd and the selected snapshot is "0" (*/LOCAL* or */REMOTE* or */CAPTURE* is mandatory)

/ENIEXPORT = config.eni

Activates the ENI export (Optional)

/EXIEXPORT = config.exi

Activates the EXI export (Optional)

/VAREXPORT = config.var

Activates the process variables export (Optional)

/VARTYPE = "csv|plc|pd|xml" (default=csv)

Sets the format of the process variables export slave (for more information about the supported formats)

/EBIEXPORT = config.ebi

Activates the EBI (EniBuilder input file) export

/SCAN

Scans the bus after startup

/FORCEDIAG

Activates the diagnosis mode after startup. If diagnosis mode can not be activated the application will be closed.

/CYCLETIME ="1000"

Sets the master cycle time and locks it for the user

/AUTOSAVE

Current configuration will be saved automatically on exit (without asking the user if he want to discard all changes)

/ALLMASTERUNITS

If there is more than one master unit in the ecc, you can create an ENI file and variable export for all with this paramter

Samples

Run "EC-Engineer", scan automatically the local system with IP address 127.0.0.1, export ENI file and export process variables (as CSV Format) on closing

```
> EcEngineer.exe /FORCECFG="cfg_local.ecc" /EMI="emi.xml" /LOCAL=127.0.0.1
↪ /SCAN /ENIEXPORT="cfg_local.eni" /VAREXPORT="cfg_local.var"
↪ /VARTYPE="csv"
```

Run "EC-Engineer", scan automatically the remote system with IP address 127.0.0.1, Port 6000, MasterInstance 0, export ENI file and export process variables (as PLC Format) on closing

```
> EcEngineer.exe /FORCECFG="cfg_remote.ecc" /EMI="emi.xml"
↪ /REMOTE=127.0.0.1:6000:0:0 /SCAN /ENIEXPORT="cfg_remote.eni"
↪ /VAREXPORT="cfg_remote.var" /VARTYPE="plc"
```

Run EC-Engineer and switch to diagnosis mode

```
> EcEngineer.exe /FORCECFG="cfg_remote.ecc" /EMI="emi.xml"
↪ /REMOTE=127.0.0.1:6000:0:0 /FORCEDIAG
```

Run EC-Engineer and switch to offline diagnosis mode

```
> EcEngineer.exe /FORCECFG="cfg_capture.ecc" /EMI="emi.xml"  
→ /CAPTURE=C:/myfile.ccd:0 /FORCEDIAG
```

In case of an error, EC-Engineer will do the following

- Add error message to the log file (message level must be set to “All Messages”)
- If the GUI is already visible, he will show a message box
- Set exit code to “-1”


10 Customization

10.1 Multi-Language-Support

EC-Engineer supports multiple languages, which can be changed at runtime. Adding support for further languages is quite easy because it is just a simple XML file which must be added to the kit.

All language files are stored in: "%ProgramFiles%/acontis_technologies/EC-Engineer/Languages/...

EC-Engineer has also full UNICODE support, which means that it is also possible to support Asian languages:




10.2 Themes


EC-Engineer supports multiple themes, which can be changed during compile time. Adding support for further themes is quite easy because a theme consists of a couple of XAML files which must be added to the kit.

Five themes are already included into EC-Engineer:


IG Theme




Office 2010 Blue Theme




Office 2007 Black Theme



Office 2007 Sliver Theme




Luna Theme



10.3 Integration into 3rd-Party Applications

The software architecture of EC-Engineer is kept very modular:



This allows us adjust to customer needs and to integrate it into nearly every customer engineering environment. We can integrate the complete product or only parts of it, like:

View-Layer

Only changes on XAML-level needed, only a few changes are necessary to get your own look and feel

ViewModel-Layer

For a customer which has already his own GUI or wants to be very flexible

Core-Layer

- Used with CoreDemo as a commandline tool
- Used directly as library by adding the C# assembly as reference to the existing project

EniEngine-Layer

- Used with EniBuilder as a commandline tool
- Used directly as library by adding the C# assembly as reference to the existing project

If you are interested in integrating the product or parts of the product into your existing framework, please contact us.

11 Licensing

11.1 Third party Software

EC-Engineer is using the following third party software:

- Infragistics

11.2 EC-Engineer License

For EC-Engineer we have two license models:

- Node Locked License
- Floating License


11.3 Node Locked License

If you choose this license model, you need an USB dongle for every single computer. This dongle must be plugged into the computer where you want to use EC-Engineer.



11.4 Floating License


If you choose this license model, you need only one USB dongle with multiple floating licenses. This dongle must be plugged into your license server and all client computers will connect to this license server.




Note: This requires that the “WebAdmin” of the “Code Meter” is installed on the system. Please download and install the “Code Meter Runtime” from WIBU: <https://www.wibu.com/>

11.4.1 Configure License Server

Install the “Dongle-Version” of EC-Engineer on your license server, plug-in your USB dongle and open the “WebAdmin”:




In the “WebAdmin” navigate to “Configuration Server”, select the option “Run Network Server” and press *Apply*:




11.4.2 Configure Client Computer

Install the “Dongle-Version” of EC-Engineer and open the “WebAdmin”:




In the “WebAdmin” navigate to “Configuration Network”, press *add*, enter your IP address of your license server and press *Apply*:



Now, you should be able to start EC-Engineer.

Note: If too many clients are connected you will, you will receive the following error message:




In that case, you should try to close unused EC-Engineer instances or buy more floating licenses.

11.5 License Update


11.5.1 Request License Update

Step 1: Install the “Dongle-Version” of EC-Engineer and open the “CodeMeter Control Center”:






If the selected license is a virtual dongle, simply drag and drop the WibuCmLIF file onto the CodeMeter Control Center. Otherwise, the dongle should already be visible.

Step 2: In the “CodeMeter Control Center” open the “CmFAS Assistant” by clicking on *License Update*:




Step 3: Now, follow the assistant until you can select a file name:



**Step 4: Select “Create license request”:****Step 5: Select “Extend existing license”:**



Step 6: Keep the selected the vendor:



Step 7: Select the file name:

**Step 8: Finish the assistant:**

Step 9: Your license request file * .WibuCmRaC has been successfully created. Please send it to sales@acontis.com


11.5.2 Install License Update

After you have been sent your license request file you will receive the license update file *.WibuCmRaU.

Step 1: Connect your dongle.


Step 2: Copy the license update file to your desktop.

Step 3: Double-click on the license update file:




11.6 Dongle Firmware Update


Step 1: Install the “Dongle-Version” of EC-Engineer and open the “CodeMeter Control Center”:




Step 2: In the “CodeMeter Control Center” click on *Update Firmware of selected Cm Dongle*:




Step 3: Execute firmware update by pressing *OK*:



Step 4: Wait until firmware update was executed:



Step 5: Firmware update was done and dongle can be removed:



11.7 Expiration Date Dongle

If you chose a expiration dongle you can find your expiration date in the 'About Dialog'. If you have an unlimited dongle you will not see a date in the dialog.



If you see this date you can not use an Engineer which was released after the expiration date, but all older ones are possible.

If you try to start an Engineer which is newer than the expiration date, you will get the following error:

WIBU-SYSTEMS Software Protection ✕

Required License (Dongle/File) not available.

CodeMeter 101409:285278208 Das Releasedatum befindet sich außerhalb des geforderten Intervalls, Fehler 77.

CodeMeterAct 5000087:285278208 CmContainer-Eintrag nicht gefunden, Fehler 200.

CodeMeterAct 6001978:285278208 CmContainer-Eintrag nicht gefunden, Fehler 200.

12 FAQ, Tips

12.1 Problems with install or uninstall

If you have a problem with the setup of the EC-Engineer remove the following keys and folders to uninstall EC-Engineer manually:

```
C:/Program Files (x86)/acontis_technologies/EC-Engineer
```

```
C:/ProgramData/EC-Engineer
```

```
C:/Windows/Installer/{07985CE9-9024-422C-8E72-C449BFC33CA0}
```

```
&temp%
```

```
HKEY_LOCAL_MACHINE/SOFTWARE/Microsoft/Windows/CurrentVersion/Uninstall/  
{07985CE9-9024-422C-8E72-C449BFC33CA0}
```

```
HKEY_LOCAL_MACHINE/SOFTWARE/acontis technologies/EC-Engineer
```

```
HKEY_LOCAL_MACHINE/SOFTWARE/Classes/Installer/Products/  
9EC589704209C224E8274C94FB3CC30A
```

After these steps try to install EC-Engineer again.

12.2 Help in case of a problem

If you have a problem with EC-Engineer or something does not run as expected, please try first the following things:

- Read messages in message window
- Increase message level *Menu ▶ Settings ▶ All Messages*
- Read log file for more information *Menu ▶ Help ▶ Show ▶ Log ▶ File*
- Restart EC-Engineer and try to do it again
- **Contact support by sending a mail to ecsupport@acontis.com and attach the following information**

- Project file `.ecc`
- EC-Engineer Version *Menu ▶ Help ▶ About*
- Log file *Menu ▶ Help ▶ Show Log File*
- Short description how the reproduce it

12.3 Shortcuts

EC-Engineer supports shortcuts for the most commonly used actions, like:

Menu

- `Ctrl + N`: Create new project
- `Ctrl + O`: Open project
- `Ctrl + S`: Save project
- `Alt + F4`: Exit program

Context menu of project explorer

- `Ctrl + X`: Cut slave including all slaves
- `Ctrl + C`: Copy slave including E-Bus slaves
- `Ctrl + V`: Paste (previously cut or copied) slave

12.4 Internal User Specific Settings

EC-Engineer saves all user specific settings in a subfolder of the all users directory `%ALLUSERSPROFILE%/EC-Engineer` like `C:/ProgramData/EC-Engineer`.

In this directory there is a XML file called `User.myusername.xml`. In this file, the user can find additional settings, which can be helpful for solving some problems:

MasterUnitLocalCycleTime = 1

Bus cycle time of the internal master in milliseconds

MasterUnitLocalWorkerSleepTimeMs = 100

Cycle time of the local master thread in milliseconds

MasterUnitRemoteWorkerSleepTimeMs = 300

Cycle time of the remote master thread in milliseconds

MasterUnitTimerNormalCount = 4

- Time shift to cycle time of the normal refresh cycle
- E.g. local master = 100 ms, normal refresh cycle is every 400 ms
- Used e.g. for updating master information, error counters of slave, ...

MasterUnitTimerSlowerCount = 20

- Time shift to cycle time of the slower refresh cycle
- E.g. local master = 100 ms, slower refresh cycle is every 2 seconds
- Used e.g. for updating the slave information, EEPROM data, register data, ...

MasterUnitTimerSlowestCount = 120

- Time shift to cycle time of the slowest refresh cycle
- E.g. local master = 100 ms, slower refresh cycle is every 12 seconds
- Used e.g. for updating the CoE Object Dictionary, ...

MasterUnitScanBusTimeout = 5000

Timeout for bus scan in milliseconds

MasterUnitMailboxTimeout = 5000

Timeout for mailbox access in milliseconds

MasterUnitStateChangeTimeout = 5000

Timeout for changing state machines in milliseconds

MasterUnitRegisterTimeout = 3000

Timeout for register access in milliseconds

MasterUnitProcessDataTimeout = 1000

Timeout for process data access in milliseconds

MasterUnitEepromTimeout = 3000

Timeout for EEPROM access in milliseconds

MasterUnitRasCycleTime = 0

Internal RAS cycle time for polling

MasterUnitRasWatchDog = 0

Internal RAS watchdog interval

MasterUnitRasWdToLimit = 0

Internal RAS watchdog limit

DiagGeneralErrorLvlLostLink = 10

Threshold value for the “Lost Link Errors”, which leads to an error

DiagGeneralWarningLvlLostLink = 1

Threshold value of the “Lost Link Errors”, which leads to a warning

DiagGeneralErrLvlRxError = 10

Threshold value for the “RX Errors”, which leads to an error

DiagGeneralWarnLvlRxError = 0.001

Threshold value of the “RX Errors”, which leads to a warning

DiagGeneralErrLvlInvalidFrame = 10

Threshold value for the “Invalid Frames”, which leads to an error

DiagGeneralWarnLvlInvalidFrame = 0.001

Threshold value of the “Invalid Frames”, which leads to a warning

DiagGeneralErrLvlProcUnitErr = 1000

Threshold value for the “Processing Unit Errors”, which leads to an error

DiagGeneralWarnLvlProcUnitErr = 100

Threshold value of the “Processing Unit Errors”, which leads to a warning

MasterDebugMessageLevel = 0

Activates extended debug messages of the EC-Master (0 = Silent, 1 = Any, 2 = Critical, 3 = Error, 4 = Warning, 5 = Info, 6 = InfoApi, 7 = Verbose, 8 = VerboseCyc)

GuiDebugMessageLevel = 0

Activates extended debug messages of the GUI (0 = Off, 1 = Errors, 2 = All)

IndentXmlFiles = False

Activates indenting of XML files (makes exported XML files readable, but increases size)

EnhancedUtf8Support = False

Activates the enhanced UTF-8 support, which might be necessary if characters will be not displayed correctly

12.5 FAQ

Here you can find solutions of possible problems:

- **The integrated EC-Master does not react as estimated**
Increase the message level (Menu Settings All Messages) and try it again.
- **EC-Engineer reports a message with ErrCode: 0x...**
Error Codes comes directly from the EC-Master. If you want to know what to know how to solve this problem, please refer the manual of EC-Master.
- **EC-Engineer reports the following message: Not all EtherCAT slave devices are in operational state**
Check if all slaves have a green icon. If the color is not green, open tab “Diagnosis Slave General”. Here you can see the error state of the slave. If it has no error, try to change the state to OP again.

- **EC-Engineer reports the following message: Changing topology failed: Bus configuration mismatch (ErrCode: 0x9811001E)**
The configured bus and the currently connected bus does not match. Please open the 'Network Mismatch Analyzer' (Menu Network Network Mismatch Analyzer) to solve the problem.
- **EC-Engineer reports the following message: Slave '...' has unexpected state (Current state: '...', Expected state: '...')**
Select the slave and open the tab "General". Here you can see the error state of the slave. If it has no error, try to change the state again.
- **Slave reports the error state: "Sync manager watchdog" (Diagnosis Slave General)**
You need a realtime operating system. If you still want to use your slave on Windows, you can turn off this watchdog (Slave->Advanced Settings: Set SM Watchdog = 0).
- **How can I configure the modules of a BK1120 slave?**
EC-Engineer supports only the MDP-Version of BK1120 slave. If you want to add this slave, enter "BK1120" into the search field, enable option "Show Hidden Slaves" and double-click on slave "BK1120 EtherCAT Fieldbus Coupler (MDP)" (Revision Number: 0x120001). The modules of this slave can be configured in tab "Modules" like in all other MDP slaves.

If you have one of the other versions of BK1120 and you want to use it, please contact our support.
- **How can I update the firmware of my slave via FoE?**

For updating the firmware of your slave via FoE, please follow these steps:

- Enable diagnosis mode
- Set master state to INIT
- Select your slave, and set his state machine to BOOTSTRAP
- Enter path of file on slave (optional)
- Enter password (optional)
- Press button "Download" (it will open the FileOpen-Dialog, where you can choose the file which contains the new firmware and uploads this file)
- **Connect to local system is not possible**
Is WinPcap / Npcap / NDIS installed?

Is at least one network adapter installed?
- **Why is the process image size different between EC-Engineer and EC-Master?**
EC-Engineer shows on tab *Process Data Image* not the real size of the process data image. It show only the offsets and the size of the variables.


If you want to get the real size of the process data image, which is used from EC-Master, you have to look into the ENI file: EtherCATConfig/Config/ProcessImage/Inputs/ByteSize or EtherCATConfig/Config/ProcessImage/Outputs/ByteSize. This is the offset + size of the last variable and additional administration data depending on the slaves which are used (ALStatus, DC Support, Mailbox, ...).
- **EC-Engineer reports the following message: Failed to query EtherCAT Slaves. No slaves found.**
Verify that WinPcap is correctly installed.

Try to restart you operating system, because this is sometimes necessary if you e.g. using a USB network adapter

Increase the message level (Menu Settings All Messages)

Turn on debug message of the master
 - Stop "EC-Engineer"

- Set “MasterDebugMessageLevel” to “7” (verbose) in %ProgramData%/EC-Engineer/user.myusername.xml
 - Start “EC-Engineer” again
- **EC-Engineer reports the following message: Network scan successful - 0 slaves found.**
Make sure you have connected the input and not the output port of your first slave to the computer.
Open “Network and Internet Connections Network Connections” and open the properties of your network adapter and uncheck all protocols except “Internet Protocol (TCP/IPv4)”



Do you have TwinCAT installed on this machine?

Open “Compatible Devices”:

General Adapter EtherCAT Online CoE - Online

Network Adapter

OS (NDIS) PCI DPRAM

Description: EtherCAT (TwinCAT-Intel PCI Ethernet Adapter (Gigabit))

Device Name: \\DEVICE\{C3BBE6DD-ADC2-4306-AA82-07F84E7E1BEF}

PCI Bus/Slot: Search...

MAC Address: 00 15 17 86 81 b7 **Compatible Devices...**

IP Address: 192.168.1.23 (255.255.255.0)

Promiscuous Mode (use with Wireshark only)


Virtual Device Names

Adapter Reference

Adapter:

Freerun Cycle (ms): 4

Uninstall or disable the “TwinCAT RT-Ethernet Adapter” for your network adapter:



If this doesn't help, try to disable the "TwinCAT RT-Ethernet Driver" in the properties of your network adapter and reboot your system.

Run EC-Engineer with administrative rights? Does it help?

Do you have a some kind of security software (like firewall, antivirus, ...) installed on this machine?

Try to turn it off and check if problem is solved

Do you have problems on sending or receiving pakets?

Install "Wireshark" and check which pakets are missing

Do you have only problems on sending packets?

Try to exclude ethernet protocol type "0x88a4" from your firewall. For more information see <https://en.wikipedia.org/wiki/EtherCAT/>

Try it with Npcap instead of WinPcap. Make sure you chose "Install Npcap in WinPcap API-compatible Mode"

- **How can I create ENI files for slaves from the Beckhoff CX5000 series?**

The ENI file of those slaves must start with an Ebus slave, but EC-Master exports only an MII port. This problem can be solved by first adding a helper slave "EK1200". The "real" EBus slaves can be connected afterwards to this helper slave.

- **WebAdmin in Dongle-Version shows page not found, what can I do?**

You have to download and install the Code Meter Runtime from WIBU <https://www.wibu.com/>

- **UTF8 characters e.g. in variables or PDOs will be not displayed correctly**

This requires the enhanced UTF-8 support and can be enabled by setting "EnhancedUtf8Support = True", (see *Internal User Specific Settings*)